



Spatial Mapping of Co valence bias dependence in LSCF Cathodes

Y. U. Idzerda*, M. Finsterbusch, and A. Lussier; *Dept. of Physics, Montana State University***


*Idzerda@montana.edu

**www.physics.montana.edu/magnetism



The Co valence of PLD deposited $\text{La}_{0.6}\text{Sr}_{0.4}\text{Co}_{0.2}\text{Fe}_{0.8}\text{O}_{3-d}$ films on GDC has been mapped with 250 μm resolution under different bias conditions (in the as-grown state, after 50 hours at 850 $^{\circ}\text{C}$ and 0 V bias, and after 50 hours at 850 $^{\circ}\text{C}$ and 500 mV bias). These large area (1 cm^2) valence mappings can be conducted in a few hours with the unique configuration of BL 6.3.1 at the the **Advanced Light Source**.

XAS Results




Conclusions

1. As-grown films are oxygen deficient, Co uniformly Co^{2+}
2. Annealing at 850 $^{\circ}\text{C}$ for 50 hrs with 0 V bias, Co valence changes to Co^{3+} , but varies substantially.
3. Operation for 50 hours at 850 $^{\circ}\text{C}$ and 500 mV bias, Sr segregation larger on the oxygen dissociation side with Co valence observed to be nearer to Co^{2+} while on the oxygen recombination the valence is nearer to Co^{4+} .
4. Spatial variation attributed to oxygen availability.

X-ray absorption process

X-ray Absorption Spectroscopy (XAS) provides for element specific electronic structure determination. Decomposition of the Co valence in a multi-valence system can be accomplished by comparison with measured or calculated reference standards and fitting. Below is shown measured XAS spectra for fully stoichiometric LSCF (6428) and CoFe_2O_4 and mixed compositions. These two reference spectra are used to fit the measured Co L_3 -edge spectra at different applied potentials.



Elke Arenholz (ALS) was largely responsible for the creation of this fast scan capability. This work is supported by the DOE (SECA) under award number DE-NT0004115.

The Advanced Light Source is supported by the Dept. of Energy.

