



ADVANCED LOW ENERGY ENZYME-CATALYZED SOLVENT FOR CO₂ CAPTURE

John Reardon; Director, Engineering
Project: DE-FE0004228
NETL National CO₂ Capture Technology Meeting;
Pittsburgh, PA

July 9, 2013

OUTLINE

- Company profile and project overview
- Technical background & fundamentals
- Progress and current status
- Summary of results
- Future work

AKERMIN INC.

Company profile

- **St. Louis-based biotechnology company**
- Developing lower cost, environmentally friendly solutions for CO₂ capture for variety of applications
- Integrating proprietary biocatalyst delivery with various solvent systems



PROJECT OVERVIEW

Participants, Duration, Funding



■ Project awardee, FFRDC, and Subcontract:



■ Enzyme Supply:



■ Test Site: (NCCC)



Fabrication:



Instrumentation:



■ Project duration: 36 months (Oct 2010 to Sept 2013)

■ Funding


DOE Funding:	\$ 3,275,043
Akermin Cost share:	\$ 2,881,695
Total Project:	\$ 6,156,738



TECHNICAL BACKGROUND AND FUNDAMENTALS

SCHEMATIC BASIC OPERATION


Indicative temperatures and pressures "simple solvent system"



*Temperatures shown here are indicative of ~ adiabatic scenario using potassium carbonate regenerated at near ambient pressure.

CORE TECHNOLOGY FOR THIS PROJECT


Coated packing: Akermin's first generation biocatalyst delivery system




Proprietary formulation achieves high activity and stability

CHEMISTRY: CA-CATALYZED CO₂ ABSORPTION

- CA accelerates hydration of CO₂ to bicarbonate:




- Base captures proton to complete reaction



- Akermis explored numerous CAs
- CA developed by Novozymes is top candidate
 - Highly active
 - Resistant to major impurities in flue gas
 - Thermostable
 - Resistant to high pH (9-10.5)
 - High expression level, few impurities

Active site of CA



$k_{cat} = 10^6/\text{sec}$




CA: Carbonic Anhydrase

Key point: CA mechanism is potentially applicable in many basic solvent systems

CATALYST REDUCES COLUMN PACKED HEIGHT

Reducing column height enables certain solvent systems to become feasible




Goal: > 10X overall improvement in packing height

BENEFITS OF TECHNOLOGY TO THE PROGRAM

The most effective and scalable method of CO₂ capture from flue gas is via chemical reaction

Desired Characteristic	Baseline (Amines)	K ₂ CO ₃
No amine aerosol emissions		x
No VOC emissions		x
No toxic air or liquid emissions		x
High Rate	x	
High/low ht rxn	high	low
Low regeneration energy potential		x
Oxidative stability		x
Low viscosity		x
Lower corrosivity		x
Low or No flue gas polishing needed		x

Estimated Costs of Greenfield Super Critical PC Power Plant with CO₂ Capture



Both CCS cases include a \$5.7 /MWh charge for CO₂ Transport, Storage and Monitoring

Technology broadens the choice of solvents to be used in CO₂ capture

TECHNICAL CHALLENGES

- Achieve long-term stability
- Minimize inhibition by flue gas impurities
- Maximize enzyme retention, minimize leaching
- Maximize activity (minimize diffusion resistance)
- Replenishment of enzyme with minimal interruption



PROGRESS AND CURRENT STATUS

BENCH UNIT CURRENTLY OPERATING AT NCCC

Installed at NCCC December 2012



- Sulzer M500X
- 8.33" ID x 26 ft packing
- Gas: 30 Nm³/hr
- Liquid: 275 LPH

Module Design and Fabrication:




Instrumentation and controls:



- Blank testing complete
- Immobilized enzyme installed and has been operating since May 2013
- Planning to operate through end of September 2013.

BENCH UNIT DATA WITH BIOCATALYST


Data at design flow (31.5 Nm³/hr, 275 LPH, XCL ~ 25%)



More than 1250 Hrs On Steam as of 7/09/2013, and continues.
Average CO₂ inlet ~ 12% (dry basis)

90% CO₂ CAPTURE TEST (~20 SCM³/hr)

Biocatalyst achieved (average) 90.1% CO₂ capture with ~20 Nm³/hr flue gas flow compared to blank estimated ~2.8 Nm³/hr flue gas flow at 90% capture.



~7-fold higher gas flow achieves 90% capture with biocatalyst compared to without biocatalyst in the current column

QUANTIFIED HEAT STABLE SALT ACCUMULATION

PRELIMINARY (1 week of data), additional results pending

Component	HSS (mg/L)	Rate moles/L /year	Loss of Solv. Capacity (%/year)
Nitrite (NO_2^{2-})	25.1	0.0283	0.83%
Nitrate (NO_3^-)	6.41	0.0054	0.16%
Sulfate (SO_4^{2-})	36.1	0.0195	1.14%
Total	67.6	0.0532	1.55%

Preliminary estimate < 2%/year loss in capacity by HSS.
Additional data and analytical results are pending.

QUANTIFIED CO₂ PURITY: ~99.98%


NCCC sampled CO₂ product and analyzed purity with Gas Chromatography

Component	Sample #1	Sample #2
O ₂	ND	ND
Ar+ O ₂	0.01%	0.01%
N ₂	0.01%	0.01%
Net CO₂	99.98%	99.98%

High selectivity is clearly demonstrated with a high purity product

VACUUM REGENERATION: ASPEN VS. DATA

This plot used for comparing Aspen prediction and regeneration energy data at test condition




Aspen model agrees within ~ 2.5% of measured values.


ENERGY & EQUIVALENT WORK VS. REBOILER TEMP.

Using lower grade steam reduces the loss of power-generating capacity for the plant!

Reboiler Heat Duty



Equiv. Work (Steam + VBLR)



- ~3.5 GJ/t_{CO₂} with K₂CO₃, basic flow sheet
- Equivalent work < 150 kWh/ t CO₂ for Steam + VBLR to 1.6 bar

SUMMARY OF RESULTS

- Demonstrated that significant acceleration of CO₂ capture is achieved with immobilized CA in the absorber
- Demonstrated 90% capture using K₂CO₃ salt solution
- Demonstrated > 1200 hours online with no detectible decline in performance
- Negligible heat stable salts accumulation
- >99.9% purity of CO₂ product
- Near zero aerosol formation
- 30% - 50% reduction in equivalent work of steam regeneration, including vacuum blower

FUTURE WORK

Outside of this project

- Complete TEA with PNNL (this project)

Beyond this project:

- Scale-up, automate, and optimize manufacture of immobilized enzyme
- Develop and demonstrate second generation replaceable enzyme delivery system
- Demonstrate alternative solvents to further reduce regeneration energy and to lower equivalent work
- Explore alternative biocatalyst-enabled flow sheets

Wrapping up current project with final TEA and report.

ACKNOWLEDGMENTS

- US DOE-NETL
 - Andrew Jones, Project Manager
- Novozymes
 - Generous supply of carbonic anhydrases
- National Carbon Capture Center
 - Test site and on-site operations support
- PNNL
 - Charles Freeman, Mark Bearden, James Collette, Dale King
- Battelle
 - Bradley Chadwell, Marty Zilka
- EPIC Systems Inc:
 - Module design, fabrication, controls programming
- Emerson:
 - Instrumentation and controls

- **DOE/NETL:** *This material is based upon work supported by the Department of Energy National Energy Technology Laboratory under Award Number DE-FE0004228.*
- **Disclaimer:** *This presentation was prepared as an account of work sponsored by an agency of the United States Government. Neither the United States Government nor any agency thereof, nor any of their employees, makes any warranty, express or implied, or assumes any legal liability or responsibility for the accuracy, completeness, or usefulness of any information, apparatus, product, or process disclosed, or represents that completeness, or usefulness of any information, apparatus, product, or process disclosed, or represents that its use would not infringe privately owned rights. Reference herein to any specific commercial product, process, or service by trade name, trademark, manufacturer, or otherwise does not necessarily constitute or imply its endorsement, recommendation, or favoring by the United States Government or any agency thereof. The views and opinions of authors expressed herein do not necessarily state or reflect those of the United States Government or any agency.*