SOFC Testing in Cathode Air with Quantified Cr Concentration

John S. Hardy, Christopher A. Coyle, James J. Neeway, and Jeffry W. Stevenson

PRIOR WORK

Cr quantification technique was inspired by work by Jan Froitzhiem, et al.

- ECS Trans., 25(2) 1423-8 (2009).
- J. of the Electrochem. Soc., **157**(9) B1295-300 (2010).
- J of Power Sources, **220** 217-27 (2012).
- ECS Trans., **50**(44) 43-9 (2013).
- J. of the Electrochem. Soc., **161**(9) C373-81 (2014).

They used a single denuder tube as illustrated in their publication on Cr volatility from metallic SOFC interconnects [J of Power Sources, 220 217-27 (2012)]:



95+/-5% Cr collection efficiency was achieved independent of flow-rate

The denuder tube is coated with Na₂CO₃ which reacts with Cr-species to form water soluble Na₂CrO₄

```
CrO_3(g) + Na_2CO_3(s) \rightarrow Na_2CrO_4(s) + CO_2(g)
CrO_2(OH)_2(g) + Na_2CO_3(s) \rightarrow Na_2CrO_4(s) + CO_2(g) + H_2O(g)
```

THEORETICAL EFFECTIVENESS OF CARBONATE COATING

Thermodynamic calculations of equilibrium Cr concentrations 1.0E-06 1.0E-09 mol%) 1.0E-12 1.0E-18 1.0E-21 ation L.0E-24 1.0E-27 -Over Cr2O3 in 3% H2O 1.0E-30 -Over Cr2O3 in 5 ppm H2O 1.0E-33 — Over Cr2O3 in Dry Air - - Over Na2CO3 in 3%H2O 1.0E-36 -- Over Na2CO3 in 5 ppm H2O 1.0E-39 -- Over Na2CO3 in Dry Air 1.0E-42 100 800 Temperature (C)

Sodium carbonate could reduce the concentration of Cr-species in the air by more than 8 orders of magnitude

This would mean capture of all but less than 10 ppb of the Cr released by the chromia source.



IMPLEMENTATION AT PNNL

Na₂CO₃ was coated on reticulated alumina filters for increased capacity relative to a single tube.

The alumina filters have 30 pores per inch and a spec of 3 ppm Cr or less



The filters are inserted into the test fixture downstream from the button cell



SIX TEST FIXTURES HAVE BEEN ASSEMBLED



SUMMARY

- A method of quantifying Cr in the cathode air has been implemented and validated. • Theoretical calculations and prior experimental work have shown sodium carbonate coatings to be highly effective for Cr capture.
- The Cr is captured as sodium chromate which is water soluble for easy dissolution.
- Validation tests show Cr captured by filters to be ~1-2% of the equilibrium concentration for the humidity and temperature conditions surrounding the chromia source.
- Powder chromia sources become entrained in gas stream causing uncertainty in whether captured Cr was a vapor species.
- Visual inspection of filters indicate Cr is captured at leading edge.
- Filters are not yet saturated after 600 h of testing at highest anticipated Cr concentration in air

The authors wish to thank S. Vora, B. White, J. Stoffa, R. Burke, S. Markovich, and H. Quedenfeld for their valuable discussions. This work was funded by the U.S. Department of Energy's Solid Oxide Fuel Cell Core Technology Program.



Cr FIXTURE TEST PLAN

1) Validation tests at 850°C before drilling cell ports (Complete)

mol% Crin Air Fam. mol% Cr. Meas/Th

T al al lie te 13	er mass (#8/			Nicus/ Inco	. /
Cr2O3 Powder at 800C 3% Water	306.17	2.22E-08	5.33E-07	4.17E-02	
Cr2O3 pellet at 800C 3% Water	143.21	1.06E-08	5.33E-07	1.99E-02	1 5
Cr2O3 pellet at 600C 3% Water	35.83	2.62E-09	1.28E-07	2.05E-02	1 1
Cr2O3 pellet at 800C Dry Air	0.46	3.44E-11	1.78E-09	1.93E-02	red Cr Coi
Cr2O3 pellet at 600C Dry Air	0.08	6.01E-12	2.62E-11	2.30E-01	Measu
No Cr Dry Air	0.70	5.18E-11	0	N/A	1.



2) Preliminary tests of time-to-saturation at high Cr exposure (In Progress)

Time (h)	mol% Cr in Air	Meas/Theo mol% Cr	
195	7.08E-09	1.33E-02	
312	7.17E-09	1.34E-02	
602	1.15E-08	2.16E-02	
~800	Test in Progess		
~1000	Test in Progess		

of Tests Cr2O3 Source

Yes

Yes







3) Preliminary tests of time-to-detection at low Cr exposure (In Progress)

# of Tests	Cr2O3 Source	Cr2O3 Temperature (C)	Humidity Level	Time (
1	None	N/A	<5 ppm	1000
1	Pellet	600	<5 ppm	1000
1	Pellet	800	<5 ppm	1000
1	None	N/A	<5 ppm	2000
1	Pellet	600	<5 ppm	2000
1	Pellet	800	<5 ppm	2000

4) Baseline Cr-contamination tests on LSM/YSZ button cells (*Upcoming*)

# of Tests	Cr2O3 Source	Cr2O3 Temperature (C)	Humidity Level
3	No	N/A	<5 ppm
3	Yes	800	<5 ppm

6) LSM/YSZ button cell tests seeking Cr concentration threshold below which cell performance is not significantly affected (Upcoming) 3 progressively lower Cr source temperatures in <5 ppm water

www.pnnl.gov

