




Electrochemical CO₂ Conversion at NETL

Douglas R. Kauffman (NETL / DOE)





Solutions for Today | Options for Tomorrow


Catalytic CO₂ conversion at NETL




Catalyst




Polymers & Plastics




Ethylene



Hydrogen



Carbon
Monoxide




Methanol



Fuels


Electrochemical catalyst design

Structure-controlled product selectivity




J. Mater Chem. A, 2019, 7, 27576

Surface-science enabled electrocatalysis



“Atomically Precise” nanocatalysts






JPCC, 2018, 122, 49, 27991


ACS Catalysis, 2020, 10, 12011

- Electrochemically reduce CO₂ to formate/formic acid (HCOO⁻ / HCOOH).
- Formic acid has agricultural and industrial uses.
 - Currently produced via NG reforming and methanol processing.
 - Extremely carbon intensive.
- Formic acid is also an emerging energy carrier (53 g H₂ / L)
- Key Challenges:
 - Current density
 - Stability / durability
 - Scalable catalyst synthetic procedure.


Catalyst synthesis approach




- Sphere size is fixed at ~200 nm based on PMMA template.
- Constituent SnO₂ nanoparticles are controlled between 2-10 nm with calcination in air between 300-600°C.
- Simple solution-phase synthesis and thermal processing



- XRD, XPS and Raman showed increased calcination temperature produced larger, more crystalline SnO₂ NPs.



- XRD, XPS and Raman showed increased calcination temperature produced larger, more crystalline SnO₂ NPs.
- XRD, XPS, EXAFS and Raman all confirmed SnO₂ oxidation state.




Cathode
Chamber

Anode
Chamber

- XRD, XPS and Raman showed increased calcination temperature produced larger, more crystalline SnO₂ NPs.
- XRD, XPS, EXAFS and Raman all confirmed SnO₂ oxidation state.
- SnO₂ catalysts mixed w/ 10 wt% carbon black, Nafion binder and deposited onto PTFE-coated carbon paper electrodes at 5.4 mg_{SnO2}/cm_{geo}².
- All electrochemical experiments conducted in H-Cell reactor with CO₂ saturated 0.1M KHCO₃


Catalyst Performance (Formate Selectivity)

500 °C calcined SnO₂ Nanosphere




- All catalyst synthesis temperatures selectively produced formate w/ 60-80% FE between -0.7V to -1.3V.
- 500 C calcination temperature produced highest overall formate FE.
- CO and H₂ were the only other products detected.

Catalyst Activity vs Calcination Temperature




Balance between crystallinity and particle size

- Below 500 °C the SnO₂ formed smaller and less crystalline NPs.
- Above 500 °C larger SnO₂ particle sizes formed: reduced catalyst surface area
- 500 °C was the optimum calcination temperature



- Benchmarked against commercially available SnO₂ catalyst particles (Sigma Aldrich; ~28 nm diameter NPs)
- Substantially higher formate current density at all potentials.
- Approximately 3 times larger electrochemical surface area and number of electrochemically active Sn atoms at equivalent catalyst loading.


3D morphology Boosts Surface Area and Performance



SnO₂ Nanospheres also outperformed *non-templated* SnO₂ NPs of identical size.

	Electrochemical Surface Area (cm ² / mg _{SnO₂})
NETL SnO ₂ Nanospheres	134
NETL SnO ₂ NPs	84
Comm. SnO ₂ NPs	45


Long-Term Performance at -1.2V vs. RHE




- NETL SnO₂ Nanospheres demonstrated $\geq 2x$ performance increase over SnO₂ NPs.
- All catalysts demonstrated $\sim 70\%$ Formate FE during long-term runs.
- Currently being translated into high-performance electrolyzer.

Post-Reaction Morphology


NETL SnO₂ Nanospheres



NETL SnO₂ NPs







Commercial SnO₂



Before CO₂
Reduction


After CO₂
Reduction





Time Dependent synchrotron X-Ray Diffraction shows:

- Rapid formation of ~ 25 nm metallic Sn nanoparticles with β -Sn crystallographic orientation.
- No further particle growth after initial reduction.
- In situ Raman spectroscopy confirms SnO_2 transforms into metallic Sn at operating voltages.



- 1. NETL SnO₂ Nanospheres out-perform SnO₂ NPs and commercially available SnO₂.**
 - Unique shape with extremely high surface area
 - Optimized synthetic process to maximize formate current density
 - High formate FE and selectivity
 - Stable ~25 nm nanoparticle size under steady state operation
- 2. In situ Raman and time dependent XRD show SnO₂ is quickly reduced to metallic Sn**
- 3. Ongoing work: Collaboration with NREL to evaluate NETL SnO₂ Nanospheres in recently reported formate electrolyzer**
 - Reach industrially relevant current densities (100s mA/cm²).

Acknowledgements



Electrochemistry: Thuy-Duong Nguyen-Phan

Synchrotron XRD: Argonne APS, beamline 17-BM-B; Wenqian Xu.

Synchrotron XAS: Brookhaven NSLS-II, beamline 8-ID (ISS); Eli Stavitski.

ACKNOWLEDGMENT

This work was performed in support of the US Department of Energy's Fossil Energy Carbon Use and Reuse Program. The Research was executed through the NETL Research and Innovation Center's CO₂ Utilization Technology Field Work Proposal. Research performed by Leidos Research Support Team staff was conducted under the RSS contract 89243318CFE000003. This research used Beamline 17-BM of the Advanced Photon Source, a U.S. Department of Energy (DOE) Office of Science User Facility operated for the DOE Office of Science by Argonne National Laboratory under Contract No. DE-AC02-06CH11357. This research used the 8-ID (ISS) and 23-ID-2 (IOS) beamlines of the National Synchrotron Light Source II, a U.S. Department of Energy (DOE) Office of Science User Facility operated for the DOE Office of Science by Brookhaven National Laboratory under Contract No. DE-SC0012704. .

DISCLAIMER

This work was funded by the Department of Energy, National Energy Technology Laboratory, an agency of the United States Government, through a support contract with Leidos Research Support Team (LRST). Neither the United States Government nor any agency thereof, nor any of their employees, nor LRST, nor any of their employees, makes any warranty, expressed or implied, or assumes any legal liability or responsibility for the accuracy, completeness, or usefulness of any information, apparatus, product, or process disclosed, or represents that its use would not infringe privately owned rights. Reference herein to any specific commercial product, process, or service by trade name, trademark, manufacturer, or otherwise, does not necessarily constitute or imply its endorsement, recommendation, or favoring by the United States Government or any agency thereof. The views and opinions of authors expressed herein do not necessarily state or reflect those of the United States Government or any agency thereof.


Thank you for your attention!

**We have an open post-doc / early career position for
electrolyzer testing**



Douglas.Kauffman@NETL.DOE.GOV




In situ Raman Data




Temp Dependent O1s XPS and Raman data




Temp Dependent Sn K-Edge EXAFS data



Potential Dependent Product FE




SnO₂ sphere-300




SnO₂ sphere-400

SnO₂ sphere-500



SnO₂ sphere-600



SnO₂ Nanospheres also outperformed *non-templated* SnO₂ NPs of identical size.

	Electrochemical Surface Area (cm ² / mg _{SnO₂})
NETL SnO ₂ Nanospheres	134
NETL SnO ₂ NPs	84
Comm. SnO ₂ NPs	45