

Membrane and Solvent Development for Pre-Combustion Carbon Capture

PI: Nicholas Siefert (Presenter)

TPL: David Hopkinson

RSS Solvent Research Team: Lingxiang Zhu, Robert Thompson,
Victor Kusuma, Fangming Xiang, Jeff Culp, Kevin Resnik




Applications for Physical Solvents for Gas Separation

Tailored markets: [Blue Hydrogen](#)

- Pre-combustion CO₂ Capture at IGCC-CCS
- Generation of H₂ from SMR-CCS

Polygeneration of fuels, fertilizers, & chemicals



Background and Prior Gap Analysis

Modular design




Diverse feedstocks



Location



Polygeneration



NETL
NATIONAL ENERGY TECHNOLOGY LABORATORY



Modular CO₂ Capture Processes for Integration with Modular Scale Gasification Technologies: Literature Review and Gap Analysis for Future R&D

1 October 2020




Office of Fossil Energy

DOE/NETL-2020/2149


Report available
from NETL
website: [Link](#)

Hybrid Precombustion Capture for Flexible Operations


- **Upstream H₂ selective membrane (Task 7)**
- **CO₂ selective solvent (Task 8)**



Comparison with Existing membrane technologies



J. Membr. Sci., 2012, 389, 441
TEA for IGCC-CCS process



1. *J. Mater. Chem. A*, 2018, 6, 30
2. SRI PBI: https://netl.doe.gov/sites/default/files/netl-file/21CMOG_PSC_Jayaweera_0.pdf
3. LANL PBI: US patent 2016/0375410 A1
4. Proteus: <https://www.netl.doe.gov/sites/default/files/2018-12/DOE-FE0031632-Project-Kickoff.pdf>

Cross-linked polyamide shows promising results for H₂/CO₂ separation, but its permeance (~350 GPU) needs to be higher.

Milestones:


EY22: Demonstrate a laboratory-scale coupon polyamide composite membrane with mixed-gas H₂ permeance of ≥ 500 GPU and H₂/CO₂ selectivity of ≥ 25 at 100–250°C, showing no obvious aging for 50 hours.

EY23: Complete the fabrication and assembly of a small flat-sheet membrane module, and demonstrate the membrane module with H₂ permeance of 500 GPU and H₂/CO₂ selectivity of 25 in a laboratory screening test using a simulated-shifted syngas at 100–250°C.


EY24: Completion of AspenPlus models with economic screening using experimentally determined data collected at UNDEERC and/or UK-CAER. AspenPlus models with economic screening will be done for each membrane/solvent system tested.

Approaches to higher-permeance polyamide membranes

Surface



Cross-section



J. Mater. Chem. A, 2018, 6, 30


Common commercial porous support materials	Glass transition temp.(°C)*
Polyacrylonitrile (PAN)	82 to 145
Polyethersulfone (PES)	225
Polysulfone (PSF)	179 to 194
Polyvinylidene fluoride (PVDF)	-67 to 5

* www.polymerdatabase.com, accessed on 08/2022

NETL Selected Support Material	Glass transition temp.(°C)*
Polymer X	> 400

- **Higher operating temperature** using **more thermally stable porous support** (commercial porous supports can hardly operate at or above 200 °C)
- **Thinner separation layer** via **smoothing out the wrinkled polyamide layer**

Thermally stable porous support development



H₂ permeance: 160,000 GPU* (vs. ~500 GPU for polyamide membranes)

CO₂ permeance: 44,000 GPU

H₂/CO₂: 3.7

Pressure difference rating: ≥ 13.6 bar




After thermal exposure at 200 °C for 24 h

H₂ permeance increased by 5 – 10%*

No changes on H₂/CO₂ selectivity (3.7) and surface morphology


Thinner and smoother polyamide layer development

Traditional interfacial polymerization (IP) method




Ref. *J. Mater. Chem. A*, 2018, 6, 30

Rough and wrinkled surface with a polyamide layer thickness of 100 – 300 nm





This study

A modified method produces smoother surface with a polyamide layer thickness of <30 nm



Membrane H₂/CO₂ separation performance



Selective layer: a 26-nm cross-linked polyamide
 Test condition: pure & dry gas

NETL PA: cross-linked polyamide composite membranes tested at 150 °C

PA#1 avg = 26 nm


PA#2 avg = 15 nm

Project Status and Future Work

Schedule	Milestones	Status
EY21 (Task 14 of Transformational Carbon Capture FWP)	Demonstrate a laboratory-scale coupon polyamide composite membrane with H ₂ permeance of 300 GPU and H ₂ /CO ₂ selectivity 15 at 100-250°C.	Completed
EY22 (04/22 – 03/23)	Demonstrate a laboratory-scale coupon polyamide composite membrane with mixed-gas H ₂ permeance of ≥ 500 GPU and H ₂ /CO ₂ selectivity of ≥ 25 at 100–250°C, showing no obvious aging for 50 hours.	On-track: membrane fabrication optimization & mixed-gas permeation system modification
EY23 (04/23 – 03/24)	Complete the fabrication and assembly of a small flat-sheet membrane module, and demonstrate the membrane module with H ₂ permeance of 500 GPU and H ₂ /CO ₂ selectivity of 25 in a laboratory screening test using a simulated-shifted syngas at 100–250°C.	
EY24 (04/24 – 03/25)	Completion of AspenPlus models with economic screening using experimentally determined data collected at UNDEERC and/or UK-CAER. AspenPlus models with economic screening will be done for each membrane/solvent system tested.	


Task 8: Corrosion Research Objective

- The objective of the presented task is to investigate the potential materials degradation and corrosion risks in the construction of solvent-based pre-combustion carbon capture processes and related material selection issues
- The CO₂, after being dissolved into water and converted to carbonic acid, can corrode steel equipment, and consequently damage the integrity of steels
- Presently, the corrosion rate in the presence of carbon dioxide, water, hydrogen, and capture solvents in pre-combustion cannot be estimated accurately due to lack of corrosion data at high CO₂ partial pressure
- The investigation will cover both commercial solvents and NETL-developed hydrophobic solvents used for pre-combustion applications.




Corrosion Testing Parameters

- Materials Tested: C1020 carbon steel or SS304 stainless steel
- Coupon set is submerged in 150 mL of solvent
- Solvent corrosion rates were determined by weight lost (ASTM Method G1-03)
- Gas Composition: 100% CO₂ (8 bar or 20 bar) & 50%/50% CO₂/H₂ (16 bar)
- Temperature: 21°C (uncontrolled) or at 40°C (controlled)
- Time Duration: 1, 2, 4, 8, 16 weeks




C1020 – SEM Images of Coupons


Carbon steel in 1M HCl test



before testing




before cleaning




after cleaning

Corroded C1020 - Before Cleaning

Carbon steel in 1M HCl test : SEM/EDS results



Fe in green, C in red, O in blue





Element	Weight%
Fe	63.00
C	6.34
O	30.65
Totals	100.00

Surface particles of FeCO_3 completely cover the surface of the coupon.

Corroded C1020 - After Cleaning

Carbon steel in 1M HCl test : SEM/EDS results



Element	Weight%
Fe	95.18
C	4.25
Mn	0.57
Totals	100.00

Surface particles of FeCO_3 have been removed after chemical cleaning, as shown by elimination of O atoms from the coupon.

O in blue has disappeared from the surface.

Corrosion Solvents Studied to Date

Parr reactors

Aqueous:

- DI H₂O
- 1M HCl
- 1M NaOH
- 1M NaHCO₃
- 1M Na₂CO₃
- 1M NH₄OH
- 1M NaCl
- 1M KCl
- 1M K₂CO₃

Organic:

- MDEA
- **10 wt% H₂O/Selexol**
- **2 wt% H₂O/Selexol**
- **dry Selexol**
- **TBP**
- **disub-4PEG**
- **CASSH-1**


CSTR

Aqueous:

- DI H₂O

Organic:

- CASSH-1



NETL/RIC patented hydrophobic solvents have the lowest corrosion rates

Corrosion Rates With and Without Hydrogen

CSTR testing for H₂ conditions

Corrosion Rate, $\mu\text{m}/\text{yr}$	DI Water		90% Selexol / 10% H ₂ O		CASSH1	
	25	40	25	40	25	40
Temp, °C						
CO ₂ 100%	607	624	23	43	8	13
CO ₂ /H ₂ 50%/50%	602	445	Future Testing		10	14

- On-going research to extract effect of temperature and added hydrogen to corrosion rates

Corrosion Task - Conclusions

- Corrosion rates in aqueous solvents are highest at low pH
- Corrosion of SS304 is negligible in all solutions under all conditions tested
- Corrosion of C1020 is significantly lower in organic solvents compared to aqueous solutions under all conditions tested
- NETL/RIC patented hydrophobic solvents have the lowest corrosion rates, near zero corrosion rate even for carbon steel
- NETL/RIC will be coordinating with OLI Systems to incorporate the experimental data their Corrosion Analyzer software

Acknowledgements



- NETL pre-combustion solvent research group: David Hopkinson, Kevin Resnik, Robert Thompson, Lei Hong, Fangming Xiang, Jeff Culp, Wei Shi, Jan Steckel, Kathryn Smith, Victor Kusuma, Lingxiang Zhu, Nicholas Siefert (PI)
- Dushyant Shekhawat, Reaction Engineering Team Supervisor (U.S. Department of Energy, National Energy Technology Laboratory)
- Andrew Jones, Technology Manager (U.S. Department of Energy, National Energy Technology Laboratory)
- HQ PM (Mani Gavvalapalli) and HQ DD Lynn Brickett (U.S. Department of Energy, Office of Fossil Energy)

Disclaimers & Copyright Status



- **Disclaimer of Liability:** This system is made available by an agency of the United States Government. Neither the United States Government, the Department of Energy, the National Energy Technology Laboratory, nor any of their employees, makes any warranty, express or implied, including warranties of merchantability and fitness for a particular purpose, or assumes any legal liability or responsibility for the accuracy, completeness, or usefulness of any information, apparatus, product, or process disclosed, or represents that its use would not infringe privately owned rights.
- **Disclaimer of Endorsement:** Reference herein to any specific commercial product, process, or service by trade name, trademark, manufacturer, or otherwise, does not necessarily constitute or imply its endorsement, recommendation, or favor by the United States Government, the Department of Energy, or the National Energy Technology Laboratory. The views and opinions of authors expressed herein do not necessarily state or reflect those of the United States Government, the Department of Energy, or the National Energy Technology Laboratory, and shall not be used for advertising or product endorsement purposes.
- **Copyright Status:** Most of the information available on this server is in the public domain and therefore not copyrighted. However, some of the information is copyrighted by third parties and is made available under a license granted for use by or for the government. For non-government uses, the user is responsible for securing the proper permission from the copyright holder.

- [Computational Screening of Physical Solvents for CO₂ Pre-combustion Capture](#), W Shi, SP Tiwari, RL Thompson, JT Culp, L Hong, DP Hopkinson, K Smith, ...
The Journal of Physical Chemistry B 125 (49), 13467-13481
- [Di-substituted siloxane solvents for gas capture](#), DP Hopkinson, N Siefert, RL Thompson, M Macala, L Hong, US Patent 10,589,228
- [Effect of Molecular Structure on the CO₂ Separation Properties of Hydrophobic Solvents Consisting of Grafted Poly Ethylene Glycol and Poly Dimethylsiloxane Units](#), RL Thompson, J Culp, SP Tiwari, O Basha, W Shi, K Damodaran, ...
Energy & Fuels 33 (5), 4432-4441
- 20N-25; S-166,194; U.S. Pat. App Ser. No. 17/867,094 Hydrophobic Alkyl-Ester Physical Solvents for CO₂ Removal from H₂ Produced from Synthesis Gas; U.S. Provisional Patent Application Serial No. 63/223,422; DOE Ref. No. S-166,194



Backup Slides

Aqueous CO₂ Corrosion Mechanism

CO₂ dissolution:




cathodic reactions:



anodic reaction:



overall corrosion reaction:



Cross-section morphologies of CO₂ corrosion product scales formed under low CO₂ partial pressure for 168 h immersion at 50 C (a), 80 C (b), 110 C (c) and 130 C (d) (A: epoxy, B: scale, C: steel substrate).

dense scale layer
forms protective
barrier for
subsurface Fe

Corrosion Rate Equations

gravimetric corrosion rate:

$$\text{corrosion rate} = \frac{K \times W}{A \times T \times D}$$

where K = 87,500 mm/yr (conversion factor),

W = coupon weight lost (in g),

A = coupon surface area exposed per coupon (in cm²),

T = experiment time (in hr),

and D = coupon density (in g/cm³)



this equation provides corrosion rate in units of mm/yr