# Ion Irradiation of Bulk Metallic Glass Composites for Infrastructure Resilience

Consortium for Hybrid Resilient Energy Systems Technical Forum



Jared Justice Ceramics & Polymers Engineering







## **Collaborators**

- Lawrence Livermore National Laboratory
  - Andrew Hoff, National Lab Mentor, UNM Thesis Committee Member
- University of New Mexico
  - Osman Anderoglu, Faculty Advisor, Dept. of Nuclear Engineering, UNM
- Additional Sponsors
  - Nuclear Science and Security Consortium







## **CHRES**

## **Motivation: Infrastructure Resiliency**

- High temperature corrosion in industrially relevant corrosive environments is a key challenge in maintaining US infrastructure
  - Corrosion costs the US 3% GDP per year  $^{1}$
- Metallic glasses can be used in corrosive and radioactive environments
  - Bulk Metallic Glasses (BMGs) lack grain boundaries and crystal structure, so they're radiation damage and corrosion resistant
- Applications include energy (e.g., oil & gas, geothermal), industrial production, and transportation (e.g., aeronautics)
- Metallic Glasses may serve as criticality control materials for waste packages
  - Boron is both a neutron absorber and a common BMG constituent



<sup>1</sup>Koch, G. H., Brongers, M. P.H., Thompson, N. G. et al. *Cost of Corrosion in the United States*. Handbook of Environmental Degradation of Materials, William Andrew Publishing. (2005).



## **Metallic Glass**

- Metals with an amorphous atomic structure → no long-range atomic order
- Mechanical properties between a metal and ceramic
- Created by rapidly cooling alloy: "flash freezing"
- GFA: Largest diameter rod that can be cast
- Bulk Metallic Glasses: Critical diameter above 2 mm
- Temperature Limited: Bound by glass trans. temperature







M.D Demetriou et al. (2011)





## **Metallic Glass Composites**

- Some metallic glasses suffer from poor fracture toughness
- Ductility an issue for nearly all BMGs
- Composites offer improvements
  - Crystalline phases present in an amorphous matrix
  - Requires precise cooling rates





Steel

Ni alloys

Ti allovs.

osites

Zro

Oxide

glasses

104

Metallic

glasses

Engineering metals

10

## **Radiation Damage in Materials**



Irradiation hardening and loss of ductility

Phase instability from radiation precipitation/dissolution, segregation (<0.3-0.6  $T_M$ , >0.1 dpa)

Void swelling (0.3-0.6  $T_M$ , >10 dpa)

Irradiation creep (<0.5  $T_M$ , >10 dpa)

High temperature He embrittlement (>0.5  $T_M$ , >10 dpa)

Knaster et al Nature Physics (2016)



## **Radiation Damage in Materials**



Irradiation hardening and loss of ductility

Phase instability from radiation precipitation/dissolution, segregation (<0.3-0.6  $T_M$ , >0.1 dpa)

Void swelling (0.3-0.6  $T_M$ , >10 dpa)

Irradiation creep (<0.5  $T_M$ , >10 dpa)

High temperature He embrittlement (>0.5  $T_M$ , >10 dpa)

Knaster et al Nature Physics (2016)



## **PhD Research Plan**

#### **Research Goal:**

- (1) Develop an understanding of microstructure evolution of BMG composites under irradiation
- (2) Discover candidate refractory based metallic glasses with high T<sub>g</sub>, high radiation tolerance good corrosion resistance, low cost, and acceptable processability

**Hypothesis:** Phase instability in composites leads to increased radiation hardening relative to noncomposite BMGs

#### **Summer Project:** Investigate irradiation behavior of bulk FeCrMoBC BMG composite

- Sample Production and Preparation
- Ion irradiation
- Simulation

#### **Further Work:**

- Post irradiation analysis
- Further BMG explorations
- Neutron irradiation



## **Sample Preparation**

- Powder Feedstock consolidated via SPS
- Glass formed in an Arc Melter; cast into 1/4" diameter tubes
  - Diameter of the tubes controls the cooling rate, and therefore the resultant microstructure
- Samples cut and polished to mirror finish
- Verification of amorphous microstructure XRD





## **Ion Irradiation**

- Ions can be used to simulate neutron damage in materials with less difficulty
  - High dose neutron sources are rare ATR and HFIR
  - Neutron Irradiation campaigns require long exposure time and cool down time
    - Neutrons activate samples, leaving them "hot"; sufficient time must pass before post irradiation analysis can be performed
- Ion Irradiation offers several benefits
  - High dose particle accelerators are more readily available
  - High dose irradiations can be performed quickly (<1 day vs months)</li>
  - Samples not left activated, post irradiation analysis begins immediately
- Drawbacks of Ion Irradiation
  - Materials must be neutron irradiated for licensing purposes
  - No transmutation reactions
  - Low penetration depth/uniformity





Courtesy of S. Kucheyev

## Simulated Ion Irradiation of FeCrMoBC BMG Composite

- Simulated 4 MeV He Ion beam interacting with FeCrMoBC using SRIM software
- SRIM Stopping Range of Ions in Matter
  - Monte Carlo code use for studying damage effects in materials
  - Simulation run over 100,000 ions
  - Uses Kinchin-Pease model for displacement
  - No crystal effects considered
  - Threshold displacement energies taken from literature
- Test region of ~4-5 dpa





## **Future Work**

**Post Irradiation Investigations** Microstructure evolution under irradiation

• Crystallization and changes in T<sub>g</sub>

UNM posses a wide range of testing capabilities for small samples:

- SEM/TEM Analysis
- XRD
- DSC
- Micro Hardness Testing
- Nano Mechanical Testing

#### **Further BMG Exploration**

Composites:

- Forming composites requires precise cooling rates
- Microstructure evolution not well understood

### Molybdenum Based Glass:

- High T<sub>g</sub>
- High corrosion resistance
- Relatively cost effective
- Low GFA
- Leverage AM to map large composition space

#### **Neutron Irradiations**

- Needed for validation and licensing
- Only to be performed on candidate materials
- Likely requires time in HFIR/ATR
- UNM is developing hot cell capabilities for post neutron irradiation analysis



## **Future Work**

#### Post Irradiation Investigations

Microstructure evolution under irradiation

• Crystallization and changes in T<sub>g</sub>

UNM posses a wide range of testing capabilities for small samples:

- SEM/TEM Analysis
- XRD
- DSC
- Micro Hardness Testing
- Nano Mechanical Testing

### **Further BMG Exploration**

Composites:

- Forming composites requires precise cooling rates
- Microstructure evolution not well understood

### Molybdenum Based Glass:

- High T<sub>g</sub>
- High corrosion resistance
- Relatively cost effective
- Low GFA
- Leverage AM to map large composition space

#### **Neutron Irradiations**

- Needed for validation and licensing
- Only to be performed on candidate materials
- Likely requires time in HFIR/ATR
- UNM is developing hot cell capabilities for post neutron irradiation analysis



## **Future Work**

#### Post Irradiation Investigations

Microstructure evolution under irradiation

• Crystallization and changes in T<sub>g</sub>

UNM posses a wide range of testing capabilities for small samples:

- SEM/TEM Analysis
- XRD
- DSC
- Micro Hardness Testing
- Nano Mechanical Testing

#### **Further BMG Exploration**

Composites:

- Forming composites requires precise cooling rates
- Microstructure evolution not well understood

### Molybdenum Based Glass:

- High T<sub>g</sub>
- High corrosion resistance
- Relatively cost effective
- Low GFA
- Leverage AM to map large composition space

#### **Neutron Irradiations**

- Needed for validation and licensing
- Only to be performed on candidate materials
- Likely requires time in HFIR/ATR
- UNM is developing hot cell capabilities for post neutron irradiation analysis



## **Conclusion: BMGs Can Potentially Improve Infrastructure Resiliency**

This research seeks to:

- Validate BMGs use in radioactive environments by understanding microstructure evolution under irradiation
- Support the use of BMGs in higher temperature environments by developing refractory based BMG composites
- Evaluate BMG composites for structural components supported by increased ductility

BMG composites may prove to be a viable materials for in highly corrosive, high dose, elevated temperature environments



This material is supported in part by the Department of Energy National Nuclear Security Administration through the Consortium of Hybrid Resilient Energy Systems (CHRES) under Award Number DE-NA0003982 and through the Nuclear Science and Security Consortium (NSSC) under Award Number DE-NA0003996. This work performed under the auspices of the U.S. Department of Energy by Lawrence Livermore National Laboratory under Contract DE-AC52-07NA27344.



#### Disclaimer

This document was prepared as an account of work sponsored by an agency of the United States government. Neither the United States government nor Lawrence Livermore National Security, LLC, nor any of their employees makes any warranty, expressed or implied, or assumes any legal liability or responsibility for the accuracy, completeness, or usefulness of any information, apparatus, product, or process disclosed, or represents that its use would not infringe privately owned rights. Reference herein to any specific commercial product, process, or service by trade name, trademark, manufacturer, or otherwise does not necessarily constitute or imply its endorsement, recommendation, or favoring by the United States government or Lawrence Livermore National Security, LLC. The views and opinions of authors expressed herein do not necessarily state or reflect those of the United States government or Lawrence Livermore National Security, LLC, and shall not be used for advertising or product endorsement purposes.

## UNM is capable of remote mechanical testing in NE hot cell (up to 900°C)





Zwick Roell AllroundLine Z020 THW was installed

A 3-zone Maytec HTO-08 furnace capable of high temperatures up to 900°C



## UNM is capable of mechanical testing at cryogenic temperatures (down to -200°C)





(left) J. Justice is having fun with manipulators installing specimen on Zwick Roell AllroundLine Z020 THW while  $LN_2$  bath is being filled by the O. Anderoglu (right)

Cryogenic temperature (~80K) was performed at 5x10<sup>-4</sup>/s displacement rate on 316SS specimens (S1).



## **BMG Failure Mode: Shear Banding**

- Failure is brittle and catastrophic
- Shear banding is a plastic deformation mode that localizes large shear strains in a thin band in the material
- Crystalline phases suppress shear band growth → composites have improved ductility



Composites showing shear band arresting by dendrites in Fe, Zr, and Ti glass families Bordeenithikasem et al. (2021)

