

A New Thermal Swing Adsorption Process for Post-Combustion Carbon Capture from Natural Gas Plants—DE-FE0032151



**Gökhan Alptekin
Ambal Jayaraman
David Gribble
Anthony Bosch
Ewa Muteba
Meredith Haanstad
Sarah DeVoss**

**TDA Research, Inc.
Wheat Ridge, CO**

**Carbon Management
Review Meeting**

August 29, 2023

Project Team and Objectives



Dr. Ashok Rao

Project Duration

- Start Date = September 23, 2022
- End Date = November 30, 2025


Budget

- Project Cost = \$3,125,000
- DOE Share = \$2,500,000
- TDA and Partners = \$625,000

- Demonstrate the viability of a transformational microwave-assisted thermal swing adsorption (MTSA) based process to efficiently capture CO₂
 - CO₂ capture efficiency target ≥ 95%
 - CO₂ product purity target ≥ 95% CO₂
 - CO₂ source is flue gas from a natural gas combined cycle power plant (simulated)
- Reduce the capture cost >25% against a reference NGCC plant with liquid amines (e.g., Cansolv®)


| BP | Period | Main Activity |
|----|--------|---|
| 1 | Year 1 | Material synthesis Adsorption & CFD modeling Bench-scale system design Preliminary TEA |
| 2 | Year 2 | Bench-scale system fabrication Commissioning/troubleshooting |
| 3 | Year 3 | Bench-scale evaluations Techno-economic Assessment Life Cycle Analysis EH&S Analysis |

2-Bed MTSA CCS Cycle




- CO₂ stripped from flue gas (>95% capture) by the system at 60°C
- Microwave heating increases the sorbent temperature to 90°C (30°C ΔT)
- Mild vacuum (10 psia or 0.68 bara) is applied to improve the CO₂ recovery
- Product stream (95% CO₂, dry basis) is conditioned and compressed
- The sorbent bed is repressurized and cooled using raw flue gas


Why Use Microwave Heating?




- **Conventional heating is slow with a large mismatch between heating and cooling time**
 - Indirect gas circulation heat is used to prevent diluting CO₂
 - Sorbents are poor thermal conductors—resulting in slow heating and poor temperature uniformity
 - Direct cooling with CO₂-laden process gas is relatively fast
- **Microwave heating is much faster**
 - Microwave heating is common in several industrial settings
 - Microwave heating can be more uniform—the RF frequency, penetration depth and reactor geometry are matched
 - Sorbent packing can be increased by eliminating heat transfer elements from the bed—reducing vessel size/cost
 - Cavity/reactor integration can limit the heat delivered to vessel, reducing waste heat and improve efficiency



How Does the Microwave Work?



- Microwave radiation is generated in the magnetron
- Radiation is coupled to a cavity by a waveguide
- Materials interact with the electromagnetic field
- Electromagnetic power losses result in direct heating of the material
- Can heat sorbents directly or through susceptors



Detailed Modeling & Simulation in BP1


A. Unloaded microwave cavity

B. Loaded microwave cavity

C. Heat distribution in load

D. Microwave/reactor model

—COMSOL modeling for biodiesel



Electromagnetic Field Model Field (Maxwell)

$$\nabla \times (\mu_r^{-1} \nabla \times \mathbf{E}) - \frac{\omega^2}{c^2} (\epsilon_r - j\sigma/\omega\epsilon_0) \mathbf{E} = 0$$

Heat Transfer Modeling (Fourier)


$$\rho C_p (\partial T / \partial t) + \nabla \cdot (-k \nabla T) = Q$$

Electromagnetic Losses (Poynting)

$$Q_{RMS} = 1/2 \{ \sigma \mathbf{E} \cdot \mathbf{E}^* + \omega \epsilon'' \mathbf{E} \cdot \mathbf{E}^* + \omega \mu_r \mathbf{H} \cdot \mathbf{H}^* \}$$

Design and Modeling of an Enhanced Microwave Reactor for Biodiesel Production: Ong & Nomanbhay; dx.doi.org/10.29322/IJSRP.8.12.2018.p8465

2-Bed MTSA CCS Cycle




| | | | | | | |
|------------|--|--|-----------------------------------|--|--|-----------------------------------|
| Time (min) | 6 | 6 | 3 | 6 | 6 | 3 |
| Bed 1 | Adsorption (CO ₂ stripped from FG) Cooling (90 → 60°C) | | | MW Heating 60 → 90°C | CO ₂ Recovery 1.05 → 0.68 bara | Pressurize 0.68 → 1.05 bara |
| Bed 2 | MW Heating 60 → 90°C | CO ₂ Recovery 1.05 → 0.68 bara | Pressurize 0.68 → 1.05 bara | Adsorption (CO ₂ stripped from FG) Cooling (90 → 60°C) | | |

- 2-bed MTSA cycle time is 30 minutes
- With conventional heating, the same ΔT would require ≥ 180 minutes
- Microwave heating is expected to yield up to a 6X increase in sorbent utilization


Adsorption Isotherm—Polymer Sorbent

CO₂ Uptake



CO₂ adsorption isotherms from 60–90°C showing working capacity of 6% wt. CO₂



CO₂ Selectivity



CO₂ and N₂ adsorption isotherms at 60°C showing selectivity >2,800

Thermogravimetric Cycling (Single-Cycle)

$\Delta T \approx 30^\circ\text{C}$; $\Delta M = 4.75\%$




- TGA tests (left) indicate that rapid CO₂ uptake and release
- CO₂ release appears to be more rapid, but in conventional TSA processes, release is the rate limiting step
- Adsorbed CO₂ is released in less than 7 minutes, when temperature is cycled from 60°C to 90°C
- TDA's sorbent maintained its stability; the apparent loss in capacity over the initial 40 cycles is lower than the cycle-to-cycle variation


Mixed-Matrix Laminates

Laminate Concept


Active Phase (Filler)




Continuous Phase (Polymer)



Small-Scale Production
(Screening Tests & Characterization)



Bench-Scale Sheets
≈ 8' x 8''




005-F



Scale-Up Equipment (MTR)


Bench-Scale Laminate Production (12" x 12")



12" x 12" mesh support



Half coated support




Fully coated support



12" x 12" laminate after drying

Early Experiments



Control Laptop

Kitchen Microwave (2.45 GHz)

Dummy Load (Water)


I/O and Control Hardware

Axial Sorbent Bed

Inert Al_2O_3 Packing

Supported Sorbent



Microwave Cavity



Gas Inlet

K-Type Thermocouple


Microwave-Assisted Regeneration



- **Heating and the subsequent CO₂ recovery are nearly instantaneous upon microwave energization—allowing for reduced regeneration cycle times while minimizing the heat transferred to the vessel**


Node Characterization

- Commercial Microwaves operate by creating a standing wave inside the microwave cavity
- This standing wave creates “hotspots” or nodes
- For a standing wave with fixed frequency, the spacing between nodes is calculated from $d = \lambda/2$
- For a kitchen microwave with a frequency of 2.45 GHz, $d \approx 6.1$ cm
- For an industrial microwave operating at 915 MHz, $d \approx 16.4$ cm
- Experimental verification of a typical kitchen microwave matches the expected (calculated) node spacing for a given plane
- Experimental images (right) show areas of color change (heating) within the microwave cavity




Sorbent Module Design—Microwave Frequency

Cavity Wavelength Optimization: 915 MHz Selected



2.45 GHz Block Heating
Model 1kW




915 MHz Block Heating
Model 1kW

Advantages


- The temperature variation is smaller for 915 MHz heating vs. 2.45 GHz heating
- High-power industrial microwaves are readily available at 915 MHz
- 915 MHz microwave generators can operate more efficiently
- At lower frequencies, the penetrating depth increases

Bench Scale System Design


Sub-Scale Model Validation and Sorbent Material Capacity Demonstration






- 3D-printed contactor for a 16-layer, sub-scale sorbent module
- Module assembled using from 3" x 3" coupons production sheets
- S-parameters are measured with a vector network analyzer and compared with COMSOL models
- A 915 MHz source and amplifier are used to validate heating models
- CO₂ adsorption/desorption will be tested to validate adsorption models and demonstrate sorbent capacity



Custom-made validation cavity with dual 915 MHz waveguide-to-coax transitions




Structured Sorbent Preparation




Sorbent films are laser cut (A and stacked alternating with spacer grids in a holder (C and D) to make a module or stack (E)

Sorbent Module Design—Cavity Modeling

Bench-scale microwave cavity and sorbent stack placement have been optimized for field uniformity at 915 MHz




Optimized cavity & EM field distribution



Optimized cavity with discrete Analysis points

Numerical modeling calculates the temperature for a constant array of points—allowing for quantitative comparison of heating concepts


Sorbent Module Design—Modeling Assumptions



Sorbent Stack in Cavity at 540sec.
(average sorbent temp = 60°C)


- 915 MHz microwave
- 9-minute heating cycle
- 38-layer sorbent stack
- Laminate thickness = 4mm
- Laminate spacing = 8mm
- Laminate area = 1 ft³
(12" x 12" x 12")

COMSOL Modeled Sorbent Average Temperature





| Property | V _i | Value | Unit | Property group |
|--|----------------|------------------------|-------------------|-----------------------------------|
| <input checked="" type="checkbox"/> Relative permeability | m. | 1 | 1 | Basic |
| <input checked="" type="checkbox"/> Thermal conductivity | k... | 9.225 | W/(m·K) | Basic |
| <input checked="" type="checkbox"/> Density | r... | 5258.3 | kg/m ³ | Basic |
| <input checked="" type="checkbox"/> Heat capacity at constant pressure | C.. | 1296 | J/(kg·K) | Basic |
| <input checked="" type="checkbox"/> Loss tangent, dissipation factor | t... | 0.0189 | 1 | Loss tangent, dissipation fact... |
| <input checked="" type="checkbox"/> Relative permittivity (real part) | e... | 1.737 | 1 | Loss tangent, dissipation fact... |
| Electrical conductivity | s... | 1.45*10 ⁻¹³ | S/m | Basic |

Sorbent Module Design—Cavity Design




Sorbent Module Design Optimization

- Cavity is modeled with several waveguides/ports
- Electromagnetic field distribution is modeled using COMSOL for each combination
- A reinforcement learning algorithm is employed to determine the optimal combination/sequence for uniform heating




Optimized

Hotter "hot" spots →
← Improved Uniformity



Standard

Sorbent Module Design—Waveguide Optimization



The field distribution from various waveguide configurations and the optimized combination (center)

Preliminary Process Design

Est. CO₂ Capture System Power

| CO ₂ Capture System Power | | TDA 90% | TDA 95% |
|--------------------------------------|-----|---------|---------|
| DCC Pump | kWe | 311 | 311 |
| Booster Blower | kWe | 8,488 | 8,488 |
| Vacuum Pump | kWe | 8,548 | 9,012 |
| Pre-Compressor | kWe | 3,774 | 3,978 |
| Microwave Power Input | kWe | 22,367 | 25,699 |

Max Allowed Microwave Power

| Microwave Power | | | TDA 90% | TDA 95% | |
|----------------------|---|------|---------|---------|-----|
| Theoretical MW Power | | | 22,367 | 25,699 | kWe |
| Sorbent Heating | % | 100% | 22,367 | 25,699 | kWe |
| Laminate Heating | % | 0% | 0 | 0 | kWe |
| Microwave Efficiency | % | 100% | 22,367 | 25,699 | kWe |


Theoretical energy requirement is being estimated from the experimental material capacity and the modeled energy required for a 1 ft³ sorbent bed.

The max allowable microwave power for sorbent regeneration (upper limit) is 80% of the power Cansolv power requirement (energy basis)—i.e., the preliminary target is a 20% reduction.

- Threshold MW power ≈ 0.36 kJ/g CO₂ (90% capture efficiency)
- Threshold MW power ≈ 0.39 kJ/g CO₂ (95% capture efficiency)

Current Budget Period Work

| Deadline | ID | Task | Title | Verification Method |
|------------|------|------|---|--------------------------------|
| 10/23/2022 | M1.1 | 1.1 | Update (PMP) | PMP File |
| 10/28/2022 | M1.2 | 1 | Kickoff Meeting | Presentation |
| 12/12/2022 | M1.3 | 1.2 | Complete Initial Technology Maturation | TMP File |
| 7/5/2023 | M1.4 | 3.0 | Prepare multiple 12"x 12" in size sorbent laminates | Pictures |
| 9/22/2023 | M1.5 | 3.1 | Demonstrate sorbent capacity ≥ 0.9 mol CO ₂ per kg at a $\Delta T=30^{\circ}\text{C}$ with 12" x 12" sorbent laminates | State Point Table |
| 7/5/2023 | M1.6 | 4.1 | Complete the detailed design of the sorbent module integrated with heating and cooling for rapid cycling | 3-D Layout in Annual Report #1 |
| 7/5/2023 | M1.7 | 5.0 | Complete Prelim process design to show TDA's system can achieve 20% reduction in CO ₂ capture energy compared to Cansolv (95% capture) | Annual Report #1 |
| 9/22/2023 | M1.8 | 5.1 | Complete Prelim TEA to show TDA's system can achieve 20% reduction in CO ₂ capture costs compared to Cansolv (95% capture) | |
| 7/5/2023 | | | BP2 Continuation Application | Annual Report #1 |



Future Work

Budget Period 2:

- **Task 6. Fabrication of the Bench-scale System (2–3 scfm of simulated flue gas)**
 - Subtask 6.1. Sorbent Reactor Module Fabrication
 - Subtask 6.2. Modifications to Bench-Scale System
- **Task 7. Accelerated Sorbent Module Life Tests**

Budget Period 3:

- **Task 8. Shakedown Testing**
- **Task 9. Full-scale System Design**
- **Task 10. Bench Scale System Testing and Optimization**
- **Task 11. Proof-of-Concept Demonstration (min 1,000 hours)**
- **Task 12. Final Techno-economic Analysis**
- **Task 13. Life Cycle Analysis**
- **Task 14. Environmental Health & Safety Assessment**

Acknowledgments

- **DOE Funding: Contract DE-FE0032151**
- **DOE Program Manager: Dustin M. Brown**
- **TDA Electrical Engineers: Josh Wewerka and David Long**
- **TDA Chemists: Ewa Muteba, Meredith Haanstad, and Sarah DeVoss**
- **MTR: Tim Merkel, Jay Kniep, and Jenny He**
- **Comsol Technical Support**

Disclaimer: "This report was prepared as an account of work sponsored by an agency of the United States Government. Neither the United States Government nor any agency thereof, nor any of their employees, makes any warranty, express or implied, or assumes any legal liability or responsibility for the accuracy, completeness, or usefulness of any information, apparatus, product, or process disclosed, or represents that its use would not infringe privately owned rights. Reference herein to any specific commercial product, process, or service by trade name, trademark, manufacturer, or otherwise does not necessarily constitute or imply its endorsement, recommendation, or favoring by the United States Government or any agency thereof. The views and opinions of authors expressed herein do not necessarily state or reflect those of the United States Government or any agency thereof."