

Transformational Molecular Layer Deposition Tailor-Made Size-Sieving Sorbents for Post-Combustion CO₂ Capture

DE-FE0031730

Miao Yu, University of New York at Buffalo (UB)

James A. Ritter, University of South Carolina (USC)

Shiguang Li, GTI Energy

Andrew Sexton, Trimeric Corporation (Trimeric)

Patrick T. Underhill, Rensselaer Polytechnic Institute (RPI)

Project Overview


Funding: \$3,000,000 from DOE; \$759,206 Cost Share Overall Project Performance Dates: 10/1/2019-12/31/2025

Overall Project Objectives:


Develop a transformational molecular layer deposition tailor-made sorbent/PSA process (MLD-T-S/PSA) that can be installed in new or retrofitted into existing pulverized coal (PC) power plants for CO₂ capture with 95% CO₂ purity and a cost of approximately \$30 per tonne of CO₂ captured; it will be ready for demonstration by 2030.

Background & Motivation:


Integration with coal-fired power plants: installed downstream of FGD



UB's MLD-T-S for optimized CO₂ capture performance



USC's unique PSA process flow sheet from FGD to CO₂ compression



Technical and economic advantages

Advanced Sorbent Fabrication Procedure to Reduce Manufacturing Cost

- MLD/ALD for uniform internal modification from vapor phase
- Low cost MLD/ALD precursors
- Successful commercial roll-to-roll production


Ease of Scale-Up

- Pellets/beads of commercial sorbents can be directly used
- One-cycle deposition

Long-Term Stability and Ease of Regeneration


- MLD/ALD modification introduces inorganic materials (e.g., TiO₂)
- Stable base sorbent materials, such as zeolites
- Lower temperature for regeneration

USC proprietary PSA Cycle Schedule Concept




MLD-T-S: Desired PSA Performance, Contaminant Tolerance, and Scale-up

MLD-T-S Compares Favorably to 13X & UTSA-16



Contaminant Tolerable Level



Note: MLD-T-S can be fully regenerated at 200°C.

MLD-T-S Scale-up



PSA for CO₂ Capture: DAPS Simulation and 1-bed PSA testing


Simulations of a VSA System with 8 Units, 3 Feed Beds, 6 Light Reflux Beds, $R_{LD} = 1.0$, $D_p = 9$ mm and $T = 40$ °C.

USC patented multi-feed step and multi-light reflux step PSA cycle schedule


Bed 1-3	F ₁ to F ₃	
Bed 4	HR	
Bed 5	EqD	CnD
Bed 6 to 5+n _{LR}	LR ₁ to n _{LR}	
Bed 6+n _{LR}	EqU	LPP
Time	t ₁	t ₂
200 s	20 s	180 s

MLD-T-S Generally Performs Better Than 13X


Comparison of MLD2 and 13X VSA process performances via DAPS simulations: Effect of the low vacuum pressure (P_v) and the light reflux ratio (LRR) on the process performance in terms of the CO₂ purity and CO₂ recovery in the heavy.




Comparison of MLD-T-S and 13X VSA process performances via DAPS simulations: Effect of the low vacuum pressure (P_v) and the light reflux ratio (LRR) on the process performance in terms of the energy penalty.



Comparison of MLD2 and 13X VSA process performances via DAPS simulations: Effect of the low vacuum pressure (P_v) and the light reflux ratio (LRR) on the process performance in terms of the O₂ concentration in the heavy product.



Photograph of the USC 1-Bed PSA System Used for Testing Scaled Up MLD-T-S



Summary

- Optimized MLD-T-S shows improved CO₂ working capacity and CO₂/N₂ SF compared to 13X
- When exposed to CO₂/N₂ containing H₂O under an emulated P/VSA schedule, MLD-T-S showed stabilized loss in CO₂ working capacity ≤ 0.5 kPa H₂O.
- MLD-T-S was fabricated at kg-scale and sent to collaborators for P/VSA testing
- 3-bed PSA skid testing underway at USC; testing to begin soon at NCCC
- Large scale PSA process simulations continuing for process optimization
- 1-bed PSA testing with MLD2 at USC starting soon

Acknowledgments


Financial support and technical support




- DOE NETL: Dustin Brown, Dan Hancu, Sai Gollakota, Naomi Oneil
- National Carbon Capture Center (NCCC): Frank Morton, Tony Wu

PSA for CO₂ Capture: PSA Skid Construction

Front View Photograph of the USC 3-Bed PSA System




Back View Photograph of the USC 3-Bed PSA System



Status of the USC 3-Bed PSA System

- Construction 100% complete
- Start-up and troubleshooting complete
- Testing at USC underway with 13X zeolite
- Testing at USC with MLD2 zeolite will follow
- Working out details to test at the NCCC
- NCCC testing with MLD2 zeolite forthcoming

Schematic of the USC 3-Bed PSA System



LabVIEW Schematic of the USC 3-Bed PSA System

