

Status of Ammonia Combustion Research at NETL

Ammonia Combustion Working Group
May 2, 2023
Dr. Clinton Bedick
Research and Innovation Center



Disclaimer: This presentation was prepared as an account of work sponsored by an agency of the United States Government. Neither the United States Government nor any agency thereof, nor any of their employees, makes any warranty, express or implied, or assumes any legal liability or responsibility for the accuracy, completeness, or usefulness of any information, apparatus, product, or process disclosed, or represents that its use would not infringe privately owned rights. Reference herein to any specific commercial product, process, or service by trade name, trademark, manufacturer, or otherwise does not necessarily constitute or imply its endorsement, recommendation, or favoring by the United States Government or any agency thereof. The views and opinions of authors expressed herein do not necessarily state or reflect those of the United States Government or any agency thereof.

Ammonia Combustion

1. Fundamental combustion lab capabilities

2. Initial flame characterization

3. Modeling

1. 1D flame models
2. CRN models

Approach: Generate novel data sets for model validation and combustion strategy development


4. Diagnostics

1. Laminar flame speed via heat-flux method
2. Species profiles, temperature via FTIR
3. Hyperspectral imaging and UV/VIS spectrometer


5. Future research activities and interests

Fundamental Combustion Lab Capabilities

- Operational since ~May 2022
- NH₃ added to lab
 - New NH₃ gas monitor
 - 100lb vapor draw anhydrous ammonia cylinder @ ~115 psig
 - Compatible Alicat flow controller
 - Premixed, flat-flame burner
- **Lab capabilities:**
 - NH₃, NH₃/H₂(+N₂), NH₃/CH₄ mixes
 - Ability to heat air ahead of premixing (250C)
 - Ability to operate at elevated oxygen levels (21% to 100%)




McKenna stainless steel flat flame burner (60mm)



NH₃/H₂ flame in NETL
PGH FCL

Initial Flame Characterization

- Flames generated for NH_3/H_2 and NH_3/CH_4 mixes
- Stability limits evaluated qualitatively (total flow, NH_3 fraction)




Ammonia Combustion Modeling

Accelerating development of viable ammonia combustion technologies

Model Validation


1D Flames

- Cantera flame models
- Flame speed, mechanism comparisons



2D CFD


- OpenFOAM axis-symmetric
- Temperature/species profile comparisons



Combustion Strategy Development

CRN Models

- PSR-PFR, 2-stage rich-lean
- Identify candidate configurations



3D CFD

- Identify combustor configurations for experimental development/characterization




Image from <https://doi.org/10.1016/j.ijhydene.2017.09.089>

Evaluation of Chemical Kinetic Models







Figure from: Bedick et al IJECE
10.1615/InterJEnerCleanEnv.2023045330

CRN Models

- Useful to understand how to develop practical combustor configurations
- Developed in Cantera
 - PSR-PFR to represent flame and post-flame zones
 - Two-stage approach w/ secondary air injection
 - Rich stage: low NO_x, high NH₃-H₂ conversion
 - Lean stage: H₂, remaining NH₃ burnout, minimal fuel-N based NO_x
 - Compared to Chemkin/literature results



Figures from: Bedick et al IJECE
10.1615/InterJEnerCleanEnv.2023045330

Diagnostics

- Laminar flame speed: fundamental parameter related to chemical kinetics
- Substantial variability among mechanisms, experimental data
- Methods include Bunsen, combustion bomb, heat flux, velocimetry






Figure from: Zhang et al ACS Omega 2021, 6, 18, 11857–11868

Diagnostics

• Burner heat flux method:



- Determine gas velocity where flame is not heating burner and burner is not heating gases (i.e. adiabatic point)
- Requires measurement of burner face temperature profile
- IR thermometry provides direct measurement of surface temp.



Images from: Bosschaart, Karel J., "Analysis of the heat flux method for measuring burning velocities", Eindhoven : Technische Universiteit Eindhoven, .

Diagnostics

- **Burner face temperature thermometry:**
 - FLIR A8303sc camera (3-5 μ m)
- **Flame emission impacts ability to image burner emission**
 - Eliminated/reduced via filtering and post-processing corrections
 - Off-the-shelf 500nm FWHM filters provided some improvement
 - Custom 3900 nm narrow-band filter recently acquired for further reductions
- **Relative difference between burner and flame emission helps – heated via silicone oil**



Diagnostics


- **Image processing via Python**

- Perspective correction
- Nonlinear correction for I to T and surface emissivity
- T-profile fitting:


$$T(r) = T_{center}(1 - ar^2)$$

- **Interpolation of parabolic coefficient (a) vs. flow rate determines laminar flame speed**


Automated burner detection and transform calculation



Corrected top-down images vs. flow rate





T-profile fitting example



Diagnostics

- Detailed species data very limited in literature
- Of interest: NH_3 , $\text{NO}/\text{NO}_2/\text{N}_2\text{O}$, H_2O , (CO/CO_2 if CH_4 mix), NH , NH_2 , OH (and T)
- FTIR spectrometer for quantitative NH_3 , NO_x species, H_2O , and T
 - External beam passed through flame
 - Burner translated to vary measurement location
 - Abel inversion to extract centerline values
 - Lineshape fitting to determine absolute concentrations
- Leverage new HTP gas cell for lineshape data generation as needed
 - TDLs for future applications





Future Work – bench scale

- **Reformer considerations (2023)**
 - Characterize flame speeds, emissions characteristics for reformer exit comps.
- **Model combustor development and characterization (2024)**
 - Leverage existing optically accessible burner platforms, modified for ammonia
 - RQL approaches
 - Informed by 3D CFD
 - Global emissions sampling
 - Additional diagnostics (existing: OH-PLIF, PIV/LDV, new: NO-PLIF)
- **Additional interests- Non-thermal plasma for stability enhancement, NOx control**



Example model gas turbine combustor from past CH₄/H₂ work at NETL (a)



Future Work – increased scale

- Interests include atmospheric pressure industrial furnaces and high pressure gas turbine combustion
- New furnace test facility being considered at NETL MGN for ~2024+
- Leverage existing ~MW high pressure (10-30 atm) combustion facilities at NETL MGN, adapted for NH_3
 - Requires liquid NH_3 storage, vaporization, delivery

Questions?