

Richard Hart GE Global Research SOFC DOE Project Review June 14, 2018

Imagination at work.

SOFC Innovative Concepts and Core Technology ResearchDE-FOA-0001229Award FE0026169*
Trademark of General Electric Company

Metal supported SOFC cells





Low-cost manufacturing



<u>Advantages</u> Larger area / Scalable Simplified sealing Low Capex / Modular Lean Manufacturing

3

Traditional NiO(Ni)/YSZ anodes

- Advantages:
 - High initial electrochemical activity
 - Good electronic conductivity
 - Low cost
 - Well understood, wealth of data

- Disadvantages:
 - High redox Vol change (fuel \leftrightarrow air)
 - Ni particle ripening/poisoning
 - EHS concerns (NiO)
 - Sourcing concerns (REACH in Eu)



Task 2-4 Review – Metal Support Ceramic Anode Cells





Materials Screening & Engineered Powder Prep.

LST $(La_{0.35}Sr_{0.65}TiO_3)/GDC (Gd_{0.2}Ce_{0.8}O_{-1.9})$





Coupon Screening

XRD, SEM, Permeability, DE, Roughness, etc...

Experiments (Thermal Spray)





500483



100cm² Cells

(2-6 cell stacks)

OCV, W/cm2 **Redox Stability**



2018 Project Goals:

Scale 3 Ceramic Anode Candidates: Powder Scale up: 10grams -> 17kg Thermal spray and Test at ~100cm² >200mW/cm2 >3 redox cycles <10% Degradation over 1000h Eqv materials cost and process vs. baseline

5kW Stack Testing:

Repeat scale up 1-2 powders Demonstrate cell size scaling (100cm²->400cm²) ^{Task 5} Build and test 5kW stack





Ceramic Anode Material Screening Test Results GE + WVU



Material Development Testing Plan

Synthesis

- XRD impurities
- Particle Size

Conductivity Testing

- Screen w/ pressed pellets or free-standing films
- Electron Conductivity > 10S/cm (bulk), >5 S/cm (film)
- Ion Conductivity > 0.5x10⁻² S/cm (film)

Mechanical Stability During Redox Cycling (800C)

- Redox Vol. Change < 0.15% Δ V – redox dilatometry

GE + WVU screened > 200 samples (chemistry + processing)



Down-selected 3 materials / process conditions for trial under GE Task 4

Alternately Doped SrTiO3







Redox Conductivity: -Excellent conductivity -Good redox stability Redox Dilatometry: -Excellent mech redox properties

Scaling from 10g->1kg->17kg



Scale up of WVU doped-SFM at GE:



CTE in Air, $25-800^{\circ}$ C = 15.31×10^{-6} K⁻¹



Scale up experiments at GE: Calc Temp, Firing Atm, milling conditions, crucible sizes, etc...



GE Identified process to scale dSFM to 17kg quantities w/ similar electrical & mech properties!

Doped-SrFeMo Oxide 1" Button Tests- WVU



- High temperature sintering of dSFM-YSZ causes rxn
- Using GDC barrier layer or LSGM electrolyte, WVU demonstrated material entitlement for low ASR + high power density!!



GE Thermal Spray & Cell Testing Results



Task 4 – Ceramic Anode Candidate Testing

Experimental Process:



1) LST + GDC with Modified Spray Process (July –Sept 2017)



Dec 2017 – Apr 2018 Substantial delays with vendor spray drying!

All candidates used Modified T-Spray Process

Candidates 1 + 3 performed well.

Candidate 2 underperformed wrt. Expectations (post mortem in progress)



Candidate 1 LST+ GDC Modified Spray Process



LST-GDC with Modified Thermal Spray Process:

Multi-factor Designed Experiment: -LST vs LST/GDC -Anode Infiltration: *3 materials (A, B, C) *# infiltration cycles



Testing: 24 Total Cells ~100cm² cells Cells were randomly mixed into stacks

Experiment Results: -LST/GDC higher power vs. LST

-Infiltration effects weren't consistent, no clear advantage over LST/GDC (may repeat Type A again)

- Modified spray process eliminates Phase impurities \rightarrow high initial perf!

120mW/cm2* \rightarrow >200mW/cm2*



LST-GDC w/ Alt T-Spray – Reformate Testing



- Much of the voltage/power loss on reformate testing came from Lower fuel content (effect on OCV & diffusion pol)
- No sign of kinetics issues or rapid degradation acceleration



LST-GDCw/ Alt T-Spray – Degradation



- LST+GDC electrodes showed <10 % degradation over 1000h
- Infiltration with various catalysts didn't statistically improve W/cm2 or deg rate!



Candidate 3 dSFM + GDC



dSFM-GDCw/ Alt T-Spray – Coupon Experiment



XRD – Thermal Spray Film

SEM Analysis – Film X-Sections



Modified T-Spray Process: -eliminated impurity phase formation -no evidence of chemistry degradation -decent crystallinity (narrow peaks) Microstructure:

-Identified process w/ acceptable porosity -Likely still room for microstructure improvement! (best LST+GDC cells showed higher SA and porosity %)



100 cm² cell experiment centered on Conditions D/F

dSFM-GDCw/ Alt T-Spray – Cell Experiment

3 cell stacks – 2 spray conditions (minor differences)



Repeatable cell performance: >200mW/cm2 at 0.7V/33.4Uf SEM analysis of microstructure suggests further W/cm2 increase possible



Ceramic Anode Chemistries – Stack Test Highlights

Property:	LST/GDC w/ Alt T-Spray	Alt dSrTiO ₃ + GDC	dSFM + GDC
Redox Conductivity	-	+	+
Mechanical Stability	+	+	+
Power Density (mW/cm2) @ 0.7V & low Uf 100cm ² size	163-203	30-80	200-245
Degradation @1000 h	<10%	NA	> 10%
Stack Redox	+	NA	+
Estimated Porosity (%)	12-25	NA	11-17
Notes	Candidate for 5kW stack build	Post Mortem & RCA in Progress	Candidate for 5kW stack build & Further dev work!



Final Summary

- GE identified modified thermal spray method Removed phase impurities + improved W/cm2 (doubling power output!)
- 100cm² Stack Testing:

Large scale demo of ceramic anodes in metal supported stack tests Exceeded project power density targets Conducted multiple >1000h degradation stack tests

- Final Project Goal -

Deliver 5kW metal supported SOFC stack build with ceramic anodes



Acknowledgements

- GE Fuel Cells SOFC Team
- GE Global Research Team
- WVU (Dr. Sabolsky, Dr. Liu, Dr. Zondlo, & team)
- Steven Markovich @ DOE/NETL
- Funding provided by the US Department of Energy through cooperative agreement FE0026169

This material is based upon work supported by the Department of Energy under Award Number FE0026169. However, any opinions, findings, conclusions, or recommendations expressed herein are those of the authors and do not necessarily reflect the views of the DOE.



GE Team:

Rich Hart

Luc LeBlanc (GE Fuel Cells)

Holly Comanzo, Chris Hill

Jim Gardner, Jon Klopman

Matt Alinger, Todd Striker, Andy Shapiro, Simon Gaunt

Jae Hyuk Her, Yan Gao, Vince Smentkowski

John Freer, Dan Hancu, Wei Cai, Dave Moore

PI, testing & direction

Thermal Spray

Powder dev & synthesis

Materials + Cell testing

GE Fuel Cells, Systems Support

Analytical Support

GE Management Support



WVU Team

Principle Investigators: Dr. Xingbo Liu^a Dr. Edward M. Sabolsky^a Dr. John Zondlo^b

Research Assistants: Dr. Tony Thomas^a Laura (He Qi)^a

^aDepartment of Mechanical and Aerospace Engineering ^bDepartment of Chemical Engineering West Virginia University

