



Evaluation of amine-incorporated porous polymer networks (aPPNs) as sorbents for post combustion CO₂ capture

DOE AWARD NUMBER: DE-FE0026472

Project Overview

Research Team

- **Principle Investigator:** Dr. Hong-Cai “Joe” Zhou
- **Industrial partners:** Koray “Ray” Ozdemir (*framergy*)
- **Team leaders:** Jeremy Willman, Gregory Day
- **Team members:** Elizabeth Joseph, Hannah Drake, Xinyu Yang, Jialuo Li, Zachary Perry
- **Past Members:** Dr. Lanfang Zou, Dr. Mathieu Bosch, Dr. Xuan Wang, Dr. Yujia Sun, Dr. Ning Huang

Outline




- Introduction
 - Objectives
 - Porous Polymer Networks
 - PPN-151-DETA
- Sorbent Scale-up
 - Improving 250 g synthesis
 - Evaluation of Washing procedure
 - 1 kg reactor design and scale-up
- Remaining Tasks

Project Objectives

- A scalable highly-robust and highly-efficient sorbent that can be delivered and validated through lab-scale testing
- A sorbent that will be economically feasible to scale-up and use in commercial carbon capture processes
- An ideal sorbent for post-combustion CO₂ capture that will approach the goal of 90% CO₂ capture rate with 95% CO₂ purity at a cost of electricity 30% less than baseline capture approaches

Amine-decorated Porous Materials

- Porous Polymer Networks (PPNs)






A. M. Fracaroli, H. Furukawa, M. Suzuki, M. Dodd, S. Okajima, F. Gándara, J. A. Reimer, O. M. Yaghi, *J. Am. Chem. Soc.*, **2014**, 136, 8863-8866.


McDonald, T. M.; Long, J. R., *Nature* **2015**, 519 (7543), 303-308.

Lu, W.; Sculley, J. P.; Yuan, D.; Krishna, R.; Wei, Z.; Zhou, H.-C., *Angew. Chem. Int. Ed.* **2012**, 51, 7480.



Initial PPN Candidate Materials



PPN-151-DETA




PPN-151 Porosity Measurements



BET SA (m ² /g)	Pore Volume (cm ³ /g)	Average Pore Size (Å)
804	0.784	67.3





PPN-151-DETA Fixed-bed Testing Long-term Wet Cycling



Regenerative Energy Demand

- Heat of adsorption at 150 mbar CO_2 and 40°C :
 - PPN-151-DETA: 1.40 MJ/kg CO_2
- Heat capacity increases exponentially with higher temperatures
- Regenerative energy demand at 85°C
 - PPN-151-DETA: 1.8 MJ/kg CO_2

(Typical MEA process: 3.8 MJ/kg CO_2)



250 g Scale-up

- The team utilized *framergy's* 10 L jacketed solvothermal reactors to scale-up the sorbent synthesis to >250 g
- ~250 g of the sorbent was produced

Parameter	Value
Temperature	150°C
Time	5 day
Headspace	~80%
Melamine	201.62 g
Paraformaldehyde	108.00 g
Cyanuric acid	15.48 g
Dimethyl Sulfoxide (DMSO)	2080 mL
BET surface area (m²/g)	500



The Importance of Formaldehyde Morphology


The initial 250 g syntheses had low BET surface areas and showed a high degree of inhomogeneity



Initial 250 g batch utilizing granular paraformaldehyde




250 g batch utilizing powdered paraformaldehyde



Granular form slows down dissolution, causing inhomogeneity in the polymer and reducing the overall surface area

Comparison of BET Surface Area Through Scale-Up




250 g Scale-up: Processing

- *framergy's* Nutsche filter system utilized to wash sorbent (acetone, THF, DCM, methanol)
 - For 250 g batch wash with 4 L of each solvent
- Solvent Exchange (heat to 60°C in sealed Nutsche filtration device for 12 hr while agitating) twice with methanol
 - Additional 4 L






Reducing Solvent Washing: Improving Cost of Processing Steps



1 kg Scale-Up Reactor



1 kg Scale-up at Vapor Point



Reaction Set-up



PPN Removal




Parameters and Performance of 1 kg Batch



100 mL column cycling

- Previous Lab scale wet gas testing performed using a 5 mL column
- Long-term cycling tests will be done with 100 mL column
- Multiple thermocouples will inform us on temperature gradients
- Manual testing resulted in non-uniformity of runs.
 - Tests will need to be repeated upon instrument repair





Remaining Tasks

- Final cycling tasks require the fabrication of 1.5 L adsorber:
 - 400 mm double walled column, adsorber stand, heat insulation, larger mass flow controller and upgrade kit for software integration
- Instrument Manufacturer, Quantachrome Instruments, was recently bought out by Anton Paar USA Inc. delaying fabrication
- DynaSorb BT has also been shipped back for upgrades and repairs

Summary

- PPN-151-DETA can achieve > 0.1 g/g CO₂ loading at large scale
 - Parameters that have been ignored during lab scale testing can have a large impact on polymer porosity
- 1 kg synthesis performed in partnership with *framergy* and Vapor Point
 - 1 kg batch shows > 0.12 g/g CO₂
- Final cycling tests will be performed
 - 1.5 L adsorber column has been ordered from Anton Paar

Acknowledgement and Disclaimer

- Acknowledgment: "This material is based upon work supported by the Department of Energy under Award Number DE-FE0026472."
- Disclaimer: "This report was prepared as an account of work sponsored by an agency of the United States Government. Neither the United States Government nor any agency thereof, nor any of their employees, makes any warranty, express or implied, or assumes any legal liability or responsibility for the accuracy, completeness, or usefulness of any information, apparatus, product, or process disclosed, or represents that its use would not infringe privately owned rights. Reference herein to any specific commercial product, process, or service by trade name, trademark, manufacturer, or otherwise does not necessarily constitute or imply its endorsement, recommendation, or favoring by the United States Government or any agency thereof. The views and opinions of authors expressed herein do not necessarily state or reflect those of the United States Government or any agency thereof."

Acknowledgements



- DOE NETL

- Project Manager - Andrew Jones



- Framergy

- Ray Ozdemir

- Vapor Point

- Ken Mattheson

Publications

- W. M. Verdegaaal, K. Wang, J. P. Sculley, M. Wriedt and H.-C. Zhou. *ChemSusChem*, 2016, **9**, 636-643.
- Li, H.; Wang, K.; Feng, D.; Chen, Y.-P.; Verdegaaal, W.; Zhou, H.-C., *ChemSuschem*, 2016, **9**, 19, 2832-2840.
- Zou, L.; Yang, X.; Yuan, S.; Zhou, H.-C. *CrystEngComm*, 2017.
- Huang, N.; Day, G.; Yang, X.; Drake, H.; Zhou, H.-C. *Science China Chemistry*, 2017.
- Yang, X.; Zou, L.; Zhou, H.-C. *Polymer*, 2017.
- Zou, L.; Sun, Y.; Che, S.; Yang, X.; Wang, X.; Bosch, M.; Wang, Q.; Li, H.; Smith, M.; Yuan, S.; Perry, Z.; Zhou, H.-C. *Advanced Materials*, 2017