



Pacific Northwest  
NATIONAL LABORATORY

*Proudly Operated by* **Battelle** *Since 1965*

# Syngas Purifications Using High-Pressure CO<sub>2</sub>BOL Derivatives with Pressure Swing Regeneration (FWP-72564)

Phillip Koech

2019 CARBON CAPTURE, UTILIZATION, STORAGE, AND OIL AND GAS  
TECHNOLOGIES INTEGRATED REVIEW MEETING

**AUGUST 26, 2019**

NETL/DOE PROJECT MANAGER: SAI GOLLAKOTA

# Project Goals and Objectives

## Objective

- ▶ To collect critical experimental data and complete a preliminary techno-economic assessment for >90% CO<sub>2</sub> removal with an energy penalty for the CO<sub>2</sub> capture of <0.7 GJ/tonne for **pre-combustion** capture using CO<sub>2</sub>BOL HP solvents

## Tasks

- ▶ Identify candidate molecules that have high CO<sub>2</sub> selectivity compared to other components of syngas (CO, H<sub>2</sub>, and N<sub>2</sub>)
- ▶ Obtain vapor-liquid equilibria (VLE) measurements of CO<sub>2</sub>BOL HP solvents with individual components of syngas (CO, CO<sub>2</sub>, H<sub>2</sub> and N<sub>2</sub>)
- ▶ Measure solvent viscosity with and without CO<sub>2</sub>
- ▶ Perform preliminary techno-economic assessment and process performance




# Project Schedule and Milestone Status

	FY19											
	O	N	D	J	F	M	A	M	J	J	A	S
<b>Timeline</b>												
1. Project Management & Reporting												
2. VLE and viscosity measured to identify down-selected compounds												
3. Preliminary techno-economic assessment and process performance projections												

## Milestone Status

Milestone Number	Milestone Description	Estimated Completion
1.1	Updated Project Management Plan	October 31, 2018 ✓ Complete
2.1	Complete solvent down-section based on VLE and viscosity data collected using working CO <sub>2</sub> capacity, estimated pumping energy, and flash pressure as the selection criteria to enable achieving an energy penalty for CO <sub>2</sub> capture of < 0.7 GJ/tonne	May 31, 2019 ✓ Complete
3.1	Perform preliminary techno-economic assessment with the key criteria of achieving >90% CO <sub>2</sub> removal with an energy penalty for the CO <sub>2</sub> capture of < 0.7 GJ/tonne for pre-combustion capture.	June 30, 2019 ✓ Complete

# Project Team



# Assess the Viability of Water-lean Solvents for Removal of CO<sub>2</sub> from Coal-Derived Syngas

*Multidisciplinary team provides: Solvent property testing for CO<sub>2</sub> selectivity, uptake capacities, vapor liquid equilibria (VLE), kinetics, and techno-economic analysis.*

## ► Approach


- *Operando* high pressure nuclear magnetic resonance (NMR), and high-pressure autoclave reactors for preliminary solvent screening and collection of synthesis gas isotherms
- High-P NMR Enables:
  - Rapid data collection on nominal (1 mL) solvent
  - <sup>1</sup>H NMR for H<sub>2</sub> uptake
  - <sup>13</sup>C NMR for CO<sub>2</sub> and CO uptake




Operando NMR Spectroscopy

# Previous Work by PNNL on CO<sub>2</sub> & H<sub>2</sub>S Showed Water-Lean Solvents are Viable for Natural Gas Separations

*Leveraging prior work on water-lean solvents for high-pressure gas separations and applying that knowledge and solvent families for synthesis gas (syngas).*



Anhydrous ethyldiethanolamine (EDEA) absorbs H<sub>2</sub>S more strongly than physical solvents but weaker than chemical solvents.



Anhydrous EDEA absorbs CO<sub>2</sub> stronger than physical solvents but weaker than chemical solvents.


# CO<sub>2</sub> Uptake using High Pressure NMR Cell

Measuring vapor-liquid equilibrium (VLE) for PSA and TSA solvents.


Proudly Operated by **Battelle** Since 1965

	EDEA (mol%)	DMEA (mol%)	2-MAMP (mol%)	2-EAMP (mol%)
100% CO <sub>2</sub>	17.0	38.2	33	29
58 mol% H <sub>2</sub> and 42% CO <sub>2</sub>	4.6	2.7	12	14
1 mol% CO and 41 mol% CO <sub>2</sub> 58% H <sub>2</sub>	4.9	1.4	ND	ND
21 mol% N <sub>2</sub> , 18 mol% CO <sub>2</sub> and H <sub>2</sub> 61 mol%	~ 1.4	0.1	0	2.59

25 bar pressure and 25 °C




N-Ethyldiethanolamine (EDEA)




Dimethylaminoethanol (DMEA)

**Pressure Swing Absorption (PSA)**



2-[(methylamino)methyl]pyridine (MAMP)



2-[(ethylamino)methyl]pyridine (EAMP)

**Thermal Swing Absorption (TSA)** | 7

# CO<sub>2</sub> Uptake capacity for TSA compared to aMDEA

Pacific Northwest  
NATIONAL LABORATORY

Proudly Operated by Battelle Since 1965


*Gravimetric CO<sub>2</sub> uptake for Diamine (DA) and Aminopyridine (AP) shows comparable CO<sub>2</sub> capacity to aMDEA.*

Gas mix Mol%	25 bar, RT, Gravimetric (~23 °C)						Run time
	DA		AP		aMDEA		
	Wt%	Mol%	Wt%	Mol%	Wt%	Mol%	
100% CO <sub>2</sub>	26.3	129.5	25.5	103.7	19.2	100.0	18h
50% H <sub>2</sub> 50% CO <sub>2</sub>	17.9	88.1	18.4	74.9	18.3	95.4	18h
54% N <sub>2</sub> 46% CO <sub>2</sub>	13.3	65.5	17.7	72.2	18.9	98.9	18h
2.4% CO, 97.6 % CO <sub>2</sub>	18.0	89.4	23.3	94.9	20.1	104.9	18h
1% CO 41 % CO <sub>2</sub> , 58 % H <sub>2</sub>	18.7	91.7	18.0	73.5	18.7	97.6	22h
21 % N <sub>2</sub> 18% CO <sub>2</sub> 61% H <sub>2</sub>	14.1	69.2	15.0	61.2	17.3	90.6	18h



# Custom Pressure Swing Absorption Solvent (PSA-1) Developed

*Applying our learnings from molecular design of post-combustion solvents we developed a PSA with high CO<sub>2</sub> uptake and low viscosity.*



- ▶ PSA-1 has the highest CO<sub>2</sub> physical solubility of all CO<sub>2</sub>BOLs
  - ▶ **42.22** mol% CO<sub>2</sub> free (physical absorption)
- ▶ PSA-1 showed minimal chemical absorption
  - ▶ **1.38** mol% carbonate (chemical absorption)
- ▶ Total uptake capacity **43.6** mol%

# Assessing CO<sub>2</sub> Uptake from solvent blend



Pacific Northwest  
NATIONAL LABORATORY

Proudly Operated by **Battelle** Since 1965

Comparing capacity of pressure swing and thermal swing solvents  
DA:PSA-1 indicates that a blend may be the best option.


		25 bar, RT, Gravimetric (~23 °C)							
Gas mixer Mol%	DA		50:50 DA:PSA-1		65:35 DA:PSA-1		80:20 DA:PSA-1		
	Wt%	Mol%	Wt%	Mol%	Wt%	Mol%	Wt%	Mol%	
100% CO <sub>2</sub>	26.3	129.5	7.6	36.4	10.8	52.4	19.3	98.0	
50% H <sub>2</sub> and 50% CO <sub>2</sub>	17.9	88.1	10.3	49.4	13.7	66.2	13.6	67.8	
100% H <sub>2</sub>			0.02		0.2		0.3		

**PSA-1** CO<sub>2</sub> capacity 500psi at 25 °C **43.6** mol% via NMR

- ▶ No significant loss in CO<sub>2</sub> capture with binary gas mixture of 50% H<sub>2</sub> and 50% CO<sub>2</sub>
- ▶ Negligible H<sub>2</sub> solubility observed

# VLE for DA:PSA-1 (1:1) for CO<sub>2</sub>:H<sub>2</sub> (1:1) gas mixture at 35 bar


*1:1 per mole DA:PSA-1 blend has a high CO<sub>2</sub> uptake with options for regeneration*



- ▶ Normal trend of decreasing uptake capacity with temperature
- ▶ Both chemically and physically absorbed CO<sub>2</sub> on the solvent

# Viscosity vs Temperature DA:PSA-1 (1:1) at 500 psi CO<sub>2</sub>

*50:50 blend has a low viscosity while retaining high CO<sub>2</sub> uptake.*



- ▶ Viscosity decreases with temperature.
- ▶ It is comparable to aMDEA.

# Preliminary Techno-Economic Assessment

*Establishing a baseline case for comparing mixed solvents against success criteria.*

- ▶ Leveraging available experimental data from post-combustion program
  - Models developed for ASPEN Plus for EDEA and DA
  - Modeled process configurations for
    - Reference aMDEA process
    - Process configuration for EDEA:DA blend
  
- ▶ Used available experimental data from this project
  - Extracted performance from published data on aMDEA
  - Used available experimental data for PSA-1:DA to calculate performance

# Performance Comparison

*Hybrid process utilizes a bulk PSA and a polishing TSA.  
Currently unoptimized; ratio of solvent blend can be changed.*


	EDEA/DA	PZ/MDEA
Utility Consumptions		
Cooling water (GJ/hr)	83.07	213.1
Steam (GJ/hr)	56.52	203.0
Electricity (GJ/hr)	21.88	4.01
Overall Performance		
Reboiler duty (GJ/tonne CO <sub>2</sub> )	0.55	1.98
Pump duty (GJ/tonne CO <sub>2</sub> )	0.21	0.04
<b>Total (GJ/tonne CO<sub>2</sub>)</b>	<b>0.76</b>	<b>1.80</b>
Equivalent work (KJe/mol CO <sub>2</sub> )	15.1	19.1

\*Target Energy for CO<sub>2</sub> Removal: 0.7 GJ/tonne CO<sub>2</sub>

*The preliminary mixed solvent process uses lower energy and total equivalent work as compared to aMDEA.*

# Drop-in Replacement of Existing aMDEA with the New Solvent – Preliminary Calculations

*Mixture of DA and PSA-1 tested at PNNL.*



**Overall Energy for CO<sub>2</sub> capture for the new solvent ~ 0.650 GJ/tonne CO<sub>2</sub>**



# Findings of the Experimental Work

- ▶ Pressure swing solvents DMEA and EDEA show high CO<sub>2</sub> uptake capacities up to 38 mol% in pure CO<sub>2</sub> but drop to < 5 mol% in binary and ternary gas mixtures.
- ▶ Thermal swing solvents MAMP, EAMP, DA, and AP had high gravimetric CO<sub>2</sub> uptake capacity up to 129 mol% for DA, but had high viscosity in the NMR cell which prevented further evaluation.
- ▶ Modified pressure swing solvent PSA-1 had the highest physically absorbed CO<sub>2</sub> of all CO<sub>2</sub>BOLs ~44 mol%.
- ▶ A blend of DA and PSA-1 showed the best CO<sub>2</sub> uptake with with a combination of chemical and physical absorption of CO<sub>2</sub> without significant drop in uptake in binary and ternary gas mixtures.
- ▶ Viscosity of CO<sub>2</sub> rich DA:PSA-1 was measured at 16 cp at 25 °C and 500 psi CO<sub>2</sub> and decreased to 4.2 cp at 45 °C.






# TEA Summary

- ▶ Significant potential reduction in the energy for CO<sub>2</sub> capture for CO<sub>2</sub>-BOL solvents
  - Combination of physical and chemical absorption is extremely beneficial.
  - Increased use of physical adsorption enabled significant reduction in energy.
  - Maintaining some chemical absorption allows low CO<sub>2</sub> slip (~300 ppm).
  - Lower absorption energy allows greater energy reduction.
  
- ▶ Results are based on certain assumptions:
  - New solvent absorption properties are the same as similar solvents from post-combustion or natural gas sweetening.
  - Extrapolations from limited set of available experimental data on actual solvents
  - Assumption about the impact of water on the solvent performance



# Planned Year 2 Research Scope

- ▶ Determine optimal solvent formulation ratio of DA:PSA-1
- ▶ Measure VLE, viscosity, and kinetics for 3 blends under syngas conditions
- ▶ Update ASPEN process model
- ▶ Optimize process design for optimal drop-in solvent replacement



Conceptual high-P  
PVT cell to measure  
VLE, kinetics, &  
viscosity



# Acknowledgement

"This material is based upon work supported by the U.S. Department of Energy under Field Work Proposal FWP-72564."

Disclaimer: "This report was prepared as an account of work sponsored by an agency of the United States Government. Neither the United States Government nor any agency thereof, nor any of their employees, makes any warranty, express or implied, or assumes any legal liability or responsibility for the accuracy, completeness, or usefulness of any information, apparatus, product, or process disclosed, or represents that its use would not infringe privately owned rights. Reference herein to any specific commercial product, process, or service by trade name, trademark, manufacturer, or otherwise does not necessarily constitute or imply its endorsement, recommendation, or favoring by the United States Government or any agency thereof. The views and opinions of authors expressed herein do not necessarily state or reflect those of the United States Government or any agency thereof."