gti

Nano-engineered catalyst for the utilization of CO₂ in dry reforming to produce syngas

DOE Contract No. DE-FE0029760

Shiguang Li, GTI

Xinhua Liang, Missouri University of Science and Technology (Missouri S&T)



2019 Carbon Capture, Utilization, Storage, and Oil and Gas Technologies Integrated Review Meeting August 26 - 30, 2019, Pittsburgh, PA

78 History of Turning Raw Technology into Practical **Energy Solutions**





RESEARCH &

DEVELOPMENT



PROGRAM

MANAGEMENT





TECHNICAL/ ANALYTICAL

CONSULTING

TRAINING COMMERCIALIZATION







World-class piloting facilities headquartered in Chicago area


Project overview

- **Performance period**: July 1, 2017 September 30, 2020
- **Funding**: \$799,807 DOE (\$200,000 co-funding)
- **Objectives**: Develop nano-engineered catalyst supported on high-surface-area ceramic hollow fibers for the utilization of CO_2 in dry reforming of methane ($CO_2 + CH_4 \rightarrow 2 H_2 + 2 CO$) to produce syngas

Team:	Member	Roles
	gti	 Project management and planning Quality control, reactor design and testing Techno-economic analysis (TEA) and life cycle analysis (LCA)
	MISSOURI	 Catalyst development and testing



Integration of the technology with coal-fired power plants




Background of dry reforming of methane using captured CO₂

- CH₄ + CO₂ → 2H₂ + 2CO with H₂/CO ratio ≤1 due to the reverse water-gas shift reaction (CO₂ + H₂ ⇒ CO + H₂O)
 - Different from methane steam reforming (CH₄ + H₂O → CO + 3 H₂) where H₂/CO ratio >3 due to water-gas shift reaction (CO + H₂O ⇒ CO₂ + H₂)
- **Syngas**: feedstock for fuels and chemicals production
- H₂/CO ratio determines the resulting products
 - Dry reforming syngas (H_2/CO ratio = 0.7 1) can be used for producing high yield C_{5+} hydrocarbons
 - Higher H₂/CO ratio can be achieved by blending with products from steam reforming
- Typical catalysts:
 - Precious metals (Pt, Rh, Ru): expensive
 - Low-cost Ni: issue of sintering of the Ni particles




Nano-engineered Ni catalyst prepared by atomic layer deposition (ALD) may resolve sintering issue

ALD is a commercial process in semiconductor industry




C Catalysts are calcined in air at 550 °C

X-ray photoelectron spectroscopy analysis of α-Al₂O₃ nanoparticles supported Ni catalysts




TEM image of α -Al₂O₃ nanoparticle-supported Ni catalysts

- Particle size: 2-6 nm, average 3.1 nm
 - Particles prepared by traditional methods (e.g. incipient wetness) are ~10-20 nm




Packed bed catalytic reactor for dry reforming testing





ALD Ni catalyst showed advantages over traditional catalysts prepared by incipient wetness (IW)



- <u>Higher activity</u> due to highly dispersed nanoparticles: ~3.1 nm Ni particles compared to ~10-20 nm particles prepared by traditional method
- <u>Better stability</u> due to strong bonding between nanoparticles and substrates since the particles are chemically bonded to the substrate during ALD

- ALD Ni on γ -Al₂O₃ particles
- CO₂ and CH₄ cylinder gases used in testing

Novel α-Al₂O₃ hollow fiber with high packing density is being used as catalyst substrate in current project



Commercial substrates

Catalyst Geometry	SA/V (m²/m³)
1-hole	1,151
1-hole-6-grooves	1,733
4-hole	1,703
10-hole	2,013
Monolith	1,300
4-channel ceramic hollow fibers	3,000



Novel α -Al₂O₃ hollow fibers


- OD of 3.2 mm and a channel inner diameter of 1.1 mm
- Geometric surface area to volume as high as 3,000 m²/m³

ALD reactor modified for depositing catalysts onto 20-cm-long hollow fibers





Ni nanoparticles successfully deposited on 20-cmlong hollow fibers by ALD




After Ni ALD

Before Ni ALD




Dry reforming performance of the Ni ALD coated 20-cm-long hollow fibers

20-cm-long fibers were broken up into 1-cm-long fibers and tested in a packed bed reactor (CO_2 and CH_4 cylinder gases used in testing)



200-h continuous testing of 20-cm long hollow fiber supported Ni ALD catalyst indicated good stability





Designed and constructed reactor system at GTI for performance, deactivation and long-term stability tests




Furnace (reactor inside)



Future plans

In this project




After the current project

Test the technology at a larger scale with captured CO₂





- We are developing ALD nano-engineered catalysts for utilization of CO₂ in dry reforming of methane to produce syngas
- ALD nano-engineered catalyst improves activity and stability for utilization of CO₂ in dry reforming of methane to produce syngas (compared to catalysts prepared by conventional incipient wetness method)
- Uniform nano-engineered Ni nanoparticles were successfully deposited on high packing-density α-Al₂O₃ hollow fiber by ALD
- 200-h continuous testing of 20-cm long hollow fiber supported Ni ALD catalyst indicated good stability
- Designed and constructed reactor system at GTI for performance, deactivation and long-term stability tests



Acknowledgements

DE-FE0029760

Financial and technical support



- DOE NETL
 - Andrew O'Palko, Bruce Lani, José Figueroa, and Lynn Brickett
- Professor Liang Group
 - Dr. Xiaofeng Wang
 - Dr. Shoujie Ren



Disclaimer

This presentation was prepared by GTI as an account of work sponsored by an agency of the United States Government. Neither GTI, the United States Government nor any agency thereof, nor any of their employees, makes any warranty, express or implied, or assumes any legal liability or responsibility for the accuracy, completeness, or usefulness of any information, apparatus, product, or process disclosed, or represents that its use would not infringe privately owned rights. Reference herein to any specific commercial product, process, or service by trade name, trademark, manufacturer, or otherwise does not necessarily constitute or imply its endorsement, recommendation, or favoring by the United States Government or any agency thereof. The views and opinions of authors herein do not necessarily state or reflect those of the United States Government or any agency thereof.