



DOE Contract DE-FE0026383

Energy Efficient GO-PEEK Hybrid Membrane Process for Post-combustion CO₂ Capture

Shiguang Li, *GTI*

Miao Yu, *University of South Carolina (USC), and Rensselaer Polytechnic Institute (RPI)*

Yong Ding, *Air Liquide Advanced Separations (ALaS)*

Andrew Sexton and Katherine Dombrowski, *Trimeric Corporation (Trimeric)*




2019 Carbon Capture, Utilization, Storage, and Oil and Gas Technologies Integrated Review Meeting


August 26 - 30, 2019, Pittsburgh, PA

Introduction to GTI

- Research organization, providing energy and environmental solutions to the government and industry since 1941
- Facilities: 18 acre campus near Chicago



OFFICE
SUBSIDIARY










GO-PEEK project overview

- **Performance period**: Oct. 1, 2015 – Sep. 30, 2019
- **Funding**: \$1,999,995 from DOE; \$500,000 cost share



- **Objectives**: Develop a hybrid membrane process combining a graphene oxide (GO) gas separation membrane unit and a PEEK hollow fiber membrane contactor (HFMC) unit to capture $\geq 90\%$ of the CO_2 from flue gases with 95% CO_2 purity at a cost of electricity 30% less than the baseline CO_2 capture approach

| ■ <u>Team:</u> | Member | Roles |
|-----------------------|---|---|
| |  | <ul style="list-style-type: none"> ■ Project management and planning ■ Quality control and CO_2 capture performance tests |
| |   | <ul style="list-style-type: none"> ■ GO membrane development |
| |   | <ul style="list-style-type: none"> ■ PEEK membrane development |
| |   | <ul style="list-style-type: none"> ■ High-level technical & economic feasibility study |

GO membrane technology based on our work published in *Science*, *Nature Communications*, and *Journal of Membrane Science*




Ultrathin, Molecular-Sieving Graphene Oxide Membranes for Selective Hydrogen Separation

Hang Li *et al.*

Science **342**, 95 (2013);

DOI: 10.1126/science.1236686



■ Contribution:

- Single-layered GO flake prepared as thin as 1 nm
- Structural defects on GO flakes can be controlled as transport pathway for selective gas separations



ARTICLE

DOI: 10.1038/s41467-017-02318-1

OPEN

Ultrathin graphene oxide-based hollow fiber membranes with brush-like CO₂-philic agent for highly efficient CO₂ capture



Journal of Membrane Science




Volume 573, 1 March 2019, Pages 184-191



Ultrathin, ethylenediamine-functionalized graphene oxide membranes on hollow fibers for CO₂ capture


Singular PEEK HFMC technology currently at pilot scale development stage (DE-FE0012829)

Membrane contactor:
high surface area
device that facilitates
mass transfer



**PEEK spun into
high-packing
density, hollow
fibers**

**8-inch-diameter
commercial modules
with ~2,000 GPU
intrinsic CO_2
permeance used in
pilot scale testing**




NCCC PSTU solvent
system ($0.5 MW_e$)

GTI HFMC system
($0.5 MW_e$)


**Pilot plant
being tested
at NCCC**

GO-PEEK process description





- GO-PEEK uses a conventional gas separation membrane unit to capture bulk of the CO₂ from flue gas followed by a PEEK HFMC unit to further capture CO₂ to achieve DOE's technical target
- Takes advantages of the “Pros” of two processes while overcoming their “Cons”, offering opportunity to explore further reductions in CO₂ capture cost


GO-PEEK technical goals




PEEK membrane development




Under the current program, we have been developing PEEK fibers with intrinsic CO₂ permeance of 3,000 GPU



3rd Gen fibers developed; 2-inch-diameter module using the fibers showed CO₂ permeance >3,000 GPU




PEEK membrane module effective in capturing CO₂ from low CO₂-concentration feeds in membrane contactor




Goal of mass transfer coefficient > 3 (sec)⁻¹ achieved

GO membrane development




GO: single-atomic layered, oxidized graphene

An scalable procedure developed for fabrication of GO membranes on hollow fibers




Challenge: initial GO membrane performance needed significant improvement

- Initial GO membrane performance under simulated flue gas condition (humidified 15%/85% CO₂/N₂ mixture):
 - CO₂ permeance: 100 GPU; selectivity: 49




Unique GO properties + CO₂-philic agent → High performance CO₂ capture membrane


- GO: single-atomic layered, oxidized graphene



- Can be made ultra-thin, and thus high flux




- Space in between GO layers filled with CO₂-philic agent, and thus high selectivity




0.7-1.1 nm

CO₂-philic agent
example: piperazine (PZ)





- High performance GO-PZ membrane



Feed: 15% CO₂/85%N₂ with saturated water vapor
Permeate: with sweep gas

Superior performance to polymeric membranes and stable


Our GO membranes
(tested at 70-80°C)



Integrated testing ongoing, results indicated >90% CO₂ removal and >95% CO₂ purity

GO unit: Feed CO₂ concentration: 11 vol.%

- Retentate CO₂ concentration: 5.53 vol.%



PEEK unit: Feed CO₂ concentration: 5.53 vol.%

- Retentate CO₂ concentration: 0.21 vol.%
- CO₂ purity from regeneration: 96.9 vol.%


| Component | Mol % | Det. Limit | Weight % |
|------------------|--------|------------|----------|
| Helium | | 0.1% | |
| Hydrogen | | 0.1% | |
| Carbon Dioxide | 96.9% | 0.03% | 97.9% |
| Oxygen/Argon | 0.50% | 0.03% | 0.37% |
| Nitrogen | 2.62% | 0.03% | 1.68% |
| Carbon Monoxide | | 0.03% | |
| Methane | | 0.002% | |
| Ethane | | 0.002% | |
| Ethene | | 0.002% | |
| Ethyne | | 0.002% | |
| Propane | | 0.002% | |
| Propene | | 0.002% | |
| Cyclopropane | | 0.002% | |
| Propadiene | | 0.002% | |
| Propyne | | 0.002% | |
| i-Butane | | 0.002% | |
| n-Butane | | 0.002% | |
| 1-Butene | | 0.002% | |
| i-Butene | | 0.002% | |
| trans-2-Butene | | 0.002% | |
| cis-2-Butene | | 0.002% | |
| 1,3-Butadiene | | 0.002% | |
| neo-Pentane | | 0.002% | |
| i-Pentane | | 0.002% | |
| n-Pentane | | 0.002% | |
| Pentenes | | 0.002% | |
| Hexane Plus | | 0.002% | |
| Hydrogen Sulfide | | 0.10% | |
| Total | 100.0% | | 100.0% |

High-level TEA study commenced

- Completed activities
 - Process design basis
 - Process simulation (Aspen HYSYS) with heat and material balance
 - Process flowsheet with all major equipment identified
- GTI is currently completing testing to verify assumptions for
 - CO₂ flux
 - Water, NO₂ and SO₂ permeance
 - Operating temperatures
- Next steps
 - Equipment sizing and costing
 - CAPEX, OPEX, cost of CO₂ capture
 - Sensitivity studies

Future work overview/roadmap

- **In this project**







- **After this project**

- Bench-scale development for GO-based membranes (DE-FE0031598)

Summary

- We are developing a transformational **hybrid process** for CO₂ capture combining a conventional gas membrane unit and a HFMC unit to explore further reductions in the cost of CO₂ capture
- **The 3rd Generation PEEK fibers** developed to date
 - Showed intrinsic CO₂ permeance >3,000 GPU at 25°C
 - Effective in capturing CO₂ from low CO₂-concentration feeds with aMDEA solvent
- **GO-based membranes** developed to date
 - Showed CO₂ permeance > 1,000 GPU and $\alpha_{\text{CO}_2/\text{N}_2} > 600$
 - Good stability
- **Integrated GO-PEEK** testing ongoing, results indicated >90% CO₂ removal and >95% CO₂ purity. High-level TEA study commenced.



Acknowledgements

- Financial and technical support



DE-FE0026383

- DOE NETL Andrew O'Palko, Steven Mascaro. José Figueroa and Lynn Brickett
- Dr. Yu Group at RPI
- Dr. Ding Group at Air Liquide Advanced Separations

Disclaimer

This presentation was prepared by GTI as an account of work sponsored by an agency of the United States Government. Neither GTI, the United States Government nor any agency thereof, nor any of their employees, makes any warranty, express or implied, or assumes any legal liability or responsibility for the accuracy, completeness, or usefulness of any information, apparatus, product, or process disclosed, or represents that its use would not infringe privately owned rights. Reference herein to any specific commercial product, process, or service by trade name, trademark, manufacturer, or otherwise does not necessarily constitute or imply its endorsement, recommendation, or favoring by the United States Government or any agency thereof. The views and opinions of authors herein do not necessarily state or reflect those of the United States Government or any agency thereof.